Schulman Telescope StartUp Procedure

Check Internet

Go to the warm room closet and check that all internet cables are plugged in. There is one CAT5 cable that goes to the main observatory computer and another that goes directly to the telescope controller. During lightning shutdown these cables are often unplugged. While in the closet check to see that the StarDot video server is healthy.

Power up the Main Observatory Computer and UPS's

Plug in and turn on the small UPS that delivers power to the main computer and telescope services (including the TIM unit via the remotely controlled power outlets). Login to the main Windows user account. This is currently labeled "Adam" and the password is the standard "I8...." Next plug in and turn on the larger telescope controller UPS. (Do not turn on the controller yet.)

Interpret the Telescope Orientation and Clear Manual E-stops

Check the Telescope Orientation and assess the condition of the telescope. If the current position does not "make sense," consider investigating further before proceeding. If engaged, release any E-stops on the hand paddle, telescope controller, and dome controller. Although it should be in operable state by default, also check the upper shutter E-stop plunger by visual inspection. If this is inadvertently left pushed in it must be released or software shutter errors will follow. The key should be turned to the "on" position.


Check the RA Optical Tape and Read Heads

Before turning on the controller (or moving the telescope for normal operation) examine the RA axis optical tape for signs of water condensation or insect "residue." This must be cleaned before operation. Make certain both the drive and idler bearings are also free of anything that might be transferred to the optical tape. Look closely at the read heads and check to make certain they appear aligned without anything in the space between the read head and the tape. (Use a thin Tek wipe or something similar to clear the space and clean the window if necessary.)

Check the telescope Balance state

As of Fall 2016 the telescope is in a balanced state when the following conditions are met:

- 1. The CCD camera is attached to the back of the telescope. * (see note below)
- 2. There are no extra hardware or eyepieces attached to the telescope (e.g. No eyepieces should be installed in the refractor.)
- 3. The number of weights and configuration are as in the picture below:



4. **THE MIRROR COVERS ARE OPEN** This will be done shortly.

Note (Eyepieces)

The combination of the 31mm Nagler eyepiece and adapter at the back of the telescope is sufficiently close to "balanced" that it is OK to follow the startup process in this state. Being optimized for the CCD configuration permits better success at automation and recovery from errors.

Manually Point the Telescope to the Zenith

When on site for startup purposes it is OK to move the telescope against the Declination brake to point the telescope vertically (at the zenith on the meridian). This step is necessary as mountain operations currently (Fall 2016) requires the telescope be pointed "up" before opening the mirror covers. During a recovery event when the controller is one but the telescope needs to be re-homed, opening the mirror covers in other positions will still be OK. Even if the mirror covers do not fully deploy ("Mid Position")- the balanced state will be achieved and initializing the system can proceed. The mirror covers can then be closed and re-opened later.

Turn on the TIM Unit, Connect, and Open Mirror Covers


The TIM Unit must be turned on in order to open the mirror covers. Before turning it on make certain all connections are firmly seated into the enclosure. Turn the unit on with the rocker style toggle switch.

Next on the computer open the RCOS TIM software.

https://lavinia.as.arizona.edu/~tscopewiki/



Connect to the TIM unit and navigate to the "Primary Mirror Covers" tab.




Open the Mirror Covers:

connect Record Foc	user Rotator Fan Temperature	Pri. Mirror Cover
Primary Mirror Cover Contr	oller	
Cover 1	Cover 2	Open
0% 1	mA 0% 1	mA Keset
		Close
Cover 3	Cover 4	
0% 0	mA 0% 1	mA

Turn On Telescope Controller

Turn the red switch to the "on" position. Fans and other noises will be heard as the system comes on. Wait for 3 minutes for the Mic and PubSub internal computers to boot. Generally when the MIC completes booting the drives/servos are alive and holding the telescope (listen for them).



Connect to the PubSub Machine using VNC

Open VNC and type the address to PubSub shown below:


V2 VNC Viewer		—	
VNC® Vie	wer		V 2
VNC Server:	lune.as.arizona.edu:4260		~
Encryption:	Let VNC Server choose		~
About	Options	Ι	Connect

(It is assumed the user has the password.)

Initially the desktop will be blank (black). Start PubSub processes by pressing the tool utility icon at the top of desktop. It is circled in the image below:



This will clear the database and give everything a clean start. Eventually (a few minutes) the "JADE" agent will load and the desktop will look like the below:




The small icons to the right of processes can be pressed to expand them and reveal the list as shown. Once the "Instruments-xx01_0m8a_doma" process is loaded under its section PubSub is ready to communicate with the telescope (and the user). The "RPC_Gateway" process will not show up until communication to PubSub through the web browser commences. This is in the next step. It is OK to close the VNC window.

Access the LCOGT GUI

Now that the system is up and running with drives, servos, and PubSub- access the LCOGT GUI:

1. Open the Chrome Browser and click the quick link labeled PubSub (leftmost icon). You will be presented with the screen below:



The log on name is unimportant. However *default* is required for the Config File field.
Press the "OK" button to continue.

- 2. Wait for PubSub to send all of the data to the browser. It will take 2-4 minutes. If you simply have a blank/white screen → going back to PubSub through VNC may be necessary to make certain it is setup correctly.
- 3. Once the GUI comes up you will be presented with the Site heads up information. Note the small tab is labeled "tus." This stands for "Tucson." None of the capabilities on this screen are currently in use.

← → C ① pubsub.tus:8							् ★ ।
Apps 🛃 PUBSUB! 🗋 APS: V	WebRelays 🗋 Power Outlets	(Remo: 🗋 Sk	ycenter Trouble Rep	🖨 Mt. Lemmon SkyCenti 🗋	HANDOUTS 🔝 Mt. Lemmon	Observa 🕘 Satellite page: RAP Re	SDO Solar Dynamic
Tools Chat (Alan)	tus doma				TUS	Alive 2016-1	1-01 23:20:49 18:44:1
	Weather Site Boltwoo	od Thresholds	Activity Config	Harvest Reduction Services	Power		
	Agent State			Overrides		Infrastructure	
	Weather	Okay		Cloud Override	False	Sems Version	
				Sun Override	False	Panel Temp	0 °C
	Weather Control				4	Battery Voltage	0V
		Overrides	1	Values		Last Reading	A DESCRIPTION OF THE OWNER OWNER OF THE OWNER
	Cloud	Enable	Disable	Air Temp	0.0 °C	Watchdog Errors	0
	Sun	Enable	Disable	Barometric Pressure	0.0 mbar	Weather System Type	DUMMY
	Countdown to Open		Reset	Dew Point	0.0 °C	Weather System Url	
	Limits One			Electric Field	0 V/m		
		-		Humidity	0 %	Moon	
	Ok To Open	False		Weather Leaf Sensor Voltag	e Val0 mV	Topocentric Right Ascension	16:11:02.796 h
	Countdown To Open	0 sec		SQM Sky Brightness	0.00 mag/arcsec^2	Topocentric Declination	-16:40:53.857 deg
	Interlock Reason	Sun Up		Solar Insolation	0 W/m/m	Zenith Distance	61.29 deg
	Threshold Class			Wind Direction	0 deg	Azimuth	222.61 deg
	Limits Two			Wind Direction Avg	0 deg	Angular Diameter	0.49 deg
	Ok To Open	False		Wind Speed	0.00 m/s	Illumination Fraction	0.044
	Countdown To Open	0 sec		Wind Peak 12 seconds	0.00 m/s		a December 20
	Interlock Reason	Sun Up	S	Wind Peak 10 minutes	0.00 m/s	Sun	
	Threshold Class	Sun Op		Weather Rain Alert	Clear	Topocentric Right Ascension	14:30:14.616 h
	Threshold class			Particulates (1 micron)	0 parts/m^3	Topocentric Declination	-14:48:12.161 deg
	Limits Three			Boltwood Transparency Ave	rage NaN %	Zenith Distance	76.89 deg
	Ok To Open	False		Boltwood Sky Minus Ambien	t Av NaN *C	Azimuth	242.68 deg
	Countdown To Open	0 sec				Angular Diameter	0.54 deg
	Interlock Reason	Sun Up		Failures		Morning Astronomical Twlight	12:17:44.304 h
	Threshold Class	- Sur Op		Battery State		Morning Civil Twilight	13:15:31.680 h
				Electric Field Sensor State		Sunrise	13:40:55.524 h
	All Sky Camera			Humidity Sensor State		Sunset	00:33:00.972 h
Alan Alan				Leaf Sensor State		Evening Civil Twilight	00:58:21.720 h
	no alisky	camera		Particulate Sensor State		Evening Astronomical Twilight	01:56:04.272 h
Send	i lio ansky	camera	avanabic	Pressure Sensor State			
				Rain Sensor State		5ky	
	F			Sky Brightness Sensor State		Illumination	18150.0541 lux
File Operations	7			Solar Sensor State		Brightness Ratio	9075027 07

4. Click on the tab beneath "tus" to expose the information under the "doma" tab. The LCOGT software can be used to control multiple telescopes at a site. Our single site has a single telescope in the "A" dome which is roughly "doma." Again this functionality is not being used.

$\epsilon \rightarrow c$	Dubsub.tus:8080)/gwtpubsub2/#	#tus/doma/						२ 🛧 🚺
🚻 Apps 😹 P	UBSUB! 🗋 APS: Web	Relays 🕒 Powe	er Outlets (Remo	🖻 S	kycenter Trouble Rei	Mt. Lemmon SkyCent	💾 HANDOUTS 🔜 Mt. Lem	mon Observa 🛛 🎯 Satellite	page: RAP Re 🛛 📓 SDO Solar Dynamics
Tools	रर	tus					ти	S Alive	2016-11-01 23:21:19 0
Chat (Alan)	5	doma					10	Juive	18:44:49
		0m8a							
		Enclosure Contro	Facility Servic	pes por	wer Observatory Con	fig Dome Telemetry			
		Agent State				Shutters		Services	
		[not available]	2	Inot av	vailable]	[not available]	[not available]	[not available]	[not available]
		[Prototolanos]		C. State		[not available]	[not available]	[not available]	[not available]
		Enclosure				[not available]	[not available]	[not available]	[not available]
			Shutter	r Control		[not available]	[not available]	[not available]	[not available]
			pen	Both	•	[not available]	[not available]	[not available]	[not available]
		CI	lose	Both	•	(not available)	[not available]	[not available]	[not available]
		-		top	-	[not available]	(not available)	[not available]	[not available]
			r Faults Iate On	-	Reset PLC Simulate Off	[not available]	(not available)	[not available]	[not available]
		Simu	iate On		Simulate Oil	[not available]	(not available)	[not available]	[not available]
				h Contro		[not available]	[not available]	[not available]	[not available]
			ilew		deg	[not available]	[not available]	[not available]	[not available]
			sync	_	deg	[not available]	[not available]	[not available]	[not available]
			t Park		deg	[not available]	[not available]	[not available]	[not available]
			ark	-	Home	[not available]	[not available]	[not available]	[not available]
			itop Halt		Stop Reset	[not available]	[not available]	[not available]	[not available]
			late On		Clear Faults Simulate Off	[not available]	[not available]	[not available]	[not available]
		Slave	Slaved: [not avai	Slaved To: [not availab	Azimuth		[not available]	[not available]
		0m8a	• Or		Off	[not available]	(not available)	Altitude	
				gent		[not available]	[not available]	[not available]	[not available]
		1		eset		[not available]	[not available]		
			D	ilding		[not available]	[not available]	Webcam (wcama.	doma.tus.lco.gtn)
		Lights		On	Off	[not available]	[not available]		
		-				[not available]	[not available]		
		Weather		rrides able	Disable	[not available]	[not available]		
		Power		able	Disable	[not available]	[not available]		
	Alan Alan	AntiFlap	Re	eset	[not available]	[not available]	[not available]		
						[not available]	[not available]		
	Send					[not available]	[not available]		
Datum Tree						[not available]	[not available]		
File Operations						[not available]	[not available]		
Log Messages	5					[not available]	[not available]		

5. Finally click on the "0m8a" tab to expose the controls for the Schulman Telescope. This tab roughly translates to 0.8m a (or first 0.8m telescope).

Last update: 2016/11/15 public:catalinas:lemmon:schulman_32:schulman_telescope_startup_procedure https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:lemmon:schulman_32:schulman_telescope_startup_procedure&rev=1479273088 22:11
--

		0/gwtpubsub2/#tus/doma		• · · · · · · · · ·			Q & ()
III Apps [20] PUBSUB	B! [] APS: We	bRelays [] Power Outlets (R	emo: 📋 Skycenter Trouble Rej	Mt. Lemmon SkyCent] HANDOUTS 🔜 Mt. Lemmon	Observa 🧐 Satellite page:	RAP Re 📓 SDO Solar Dynamics
Tools	रर	tus doma			TUS	Alive 20	16-11-01 23:21:41
Chat (Alan)	5	0m8a					18:45:10
		umea					
		+ State Observation Script	Sequencer Source Tracking	Axes Guide Instrument	Ins View Spectrograph Calibr	ate Focus Optical Tube	Telescope Services 1 Telescope Servi
		Tracking		Description		Behaviours	
				Mount Type	1	Astrometric	133
		Disable Roll Di	sable Pitch Enable Rotator	Inform Type	12	[not available]	[not available]
			Tracking Loop	Current Message Queue Siz	•	Axes	93
		Rotator Mode		Astrometric	0	Config	18
		SKY *	Set	[not available]	[not available]	InstrumentSelector	22
		Other States		Axes	0	Monitor	9
		Astrometric Kernel State	Stopped	Config	0	[not available]	[not available]
		Astrometric	Okay	InstrumentSelector	0	Paddle	31
		[not available]	(not available)	Monitor	0	SdbAgent	10
		Container State	Okay	[not available]	[not available]	[not available]	[not available]
		Agent Count	10	Paddle	0	[not available]	[not available]
				SdbAgent	0	(not available)	[not available]
		State		[not available]	[not available]		
		Astrometric	Okay	[not available]	[not available]	Software Repository Path	
		[not available]	[not available]	[not available]	[not available]	Astrometric	issue-5613-2
		Mount	Okay	Software Revision		[not available]	[not available]
		Mount State	Okay	Investment of constant of measure	Transie	Axes	issue-5613-2
		Config	Okay	Astrometric	3b4d9fe	Config	issue-5613-2
		InstrumentSelector	Okay	[not available]	[not available]	InstrumentSelector	issue-5613-2
		Monitor	Okay	Axes	3b4d9fe	Monitor	issue-5613-2
		[not available]	[not available]	Config	3b4d9fe	[not available]	[not available]
		Paddle	Okay	InstrumentSelector Monitor	3b4d9fe 3b4d9fe	Paddle	issue-5613-2
		SdbAgent	Okay	[not available]	[not available]	SdbAgent	issue-5613-2
		[not available]	[not available]	Paddle	3b4d9fe	[not available]	[not available]
		[not available]	[not available]	SdbAgent	3b4d9fe	[not available]	[not available] [not available]
1	Alan	TestAgent	Okay	[not available]	[not available]	[not available]	[inst available]
	Alan	[not available]	[not available]	[not available]	[not available]		
		Instrument State		[not available]	[not available]		
	Send	xx01	Okay	(Januar Station of Station			
Datum Tree	5	Agent Alive Time	67344 s				
File Operations	E	Repository Revision	6a54d4e				

6. Take note of the color of the fields in the column on the left in the above image. They should all be green when the telescope is ready to be used. The "astrometric kernal" can be "yellow" when the drives are not tracking. If the telescope is tracking, this will also be green. If you come to this tab/screen quickly after rebooting PubSub, you may see fields such as "Mount State" indicate "initializing." This is OK provided that the agent does eventually initialize the drives and the field goes to green after a minute or two.


Homing the Schulman Telescope

The telescope must be homed before it can be operated.

1. Go to the *Axes* tab. Note that the axes are **Unhomed**.

tate Observation Script Sagent State	Sequencer Source	Trackin	g Axes	Guide	Instru
Mount		kay	uncered @ 20	151116	0.0.50
Axes Command			uspenu @ zv	10-11-10	96196
Agent Enable	e		Agent Disab	le	
Roll	Pitch		Rotator		
Standby	Standby		OIT		
Unhomed	Unhomed		UNKNOWN	i.	
Pos OVel	● Pos © Vel		(Pos Ovel		
0.0 deg	0.0	deg	0.0		deg
Slew	Slew			Slew	
Halt	Halt			Halt	
Home	Home	Home			
Park	Park	Park			
Unwrap	Unwrap	0			
Stop	Stop			Stop	
Stop Reset	Stop Res	et	Sto	p Reset	
Enable	Enable		E	nable	
Disable	Disable		Di	sable	
Goto Pos L1	Goto Pos	.1	Goto	Pos L1	
Goto Neg L1	Goto Neg	_1	Goto	Neg L1	
Recover L2	Recover L	2	Rec	over L2	
Fault Reset	Fault Res	et	Fau	it Reset	
	Slew		8 m -		_
	Halt				
	Park				
	Home				
	Stop				

2. Press the large HOME button (circled below) to move both axes simultaneously to the home position. See Telescope Orientation for the correct position.



3. Once homed successfully the state field will briefly go to "stopped" and then finally "L1 Positive Limit" in both axes:

Mount			Ok	ay			
Axes Command							
Age	ent Enable	N			Agent D	isable	
Roll		Pitch			Rotator		
Okay		Okay			Off		
Halted L1 Positiv	e Limit	and the second second	L1 Positive	Limit	UNKN	OWN	
● Pos ◎ Vel		. Pos	and the second		Pos		
0.0	deg	0.0		deg			de
Slew			Slew			Slew	
Halt		Halt			Halt		
Home		Home			Home		
Park			Park	Park			
Unwrap		Unwrap					
Stop			Stop			Stop	
Stop Res	et		Stop Reset		Stop Reset		
Enable		Enable			Enable		
Disable		Disable			Disable		
Goto Pos	L1		Goto Pos L1			Goto Pos L1	
Goto Neg	L1		Goto Neg L1		Goto Neg L1 Recover L2		
Recover L			Recover L2				
Fault Res	et	Fault Reset				Fault Reset	
			Slew				
			Halt				
			Park				
			Home				

4. Now go to the *Source* tab and move the telescope out of the limits to a valid sky position. If the telescope is not going to be used immediately typically the telescope is send to the park position. Remember to stop the tracking loop if observing is not going to start.

1.

← → C (i) pubsub.tus:8	080/gwtpubsub2/#tus/doma/0m	8a/Source				Q 🕁 🕻
HADDS ADDS PUBSUB! Th APS:	WebRelays	Ch Skycenter Trouble Re	Mt. Lemmon SkyCent Pi H	ANDOUTS 🚾 Mt. Lem	mon Observii 🕘 Satellite page: RAP	Re SDO Solar Dynamics
Tools	er las			9,585	2010	-11-01 23:25:14
Chat (Alan)	duma			TU	S Alive 2016	
Crief (Narr)	OmBa					18:48:46
					and the first set the	
	State Observation Scrpt 3	equencer Source Techng	Ares Oude Instrument	us View Spectrograph	Calibrate Focus Optical Tube Tele	scope Services 1 Telescope Servi
	Agent State		Source Selection		Retraction	
	Astrometric	Okay	Astrometric Kernel State: Sto	poed	Pressure:	mbar
	1 million	11102.			Humidity	%
	Point		Known objects:	• G	o Temperature:	°C
	Point/Next St	art End	Source Name: non	e Fetch	in the second	bly Override
	Skip Sto	re Clear	▼ Coordinates	· [[[ar Override
	Goto nearest pointing s	tar Clear local offsets	The second se	PARENT_HA ·	PROVIDE ALL A	
	Source		Hour Angle: 0	h	Tracking	
	11	7	Declination: 32	de	0 Disable Roll Dis	sable Pitch Enoble Rotator
	Name		Space Motion		and the first of the second	Fracking Loop
	Right Ascension Source	NaN h	Orbital Elements		Rotator Mode	interning Loop
	Declination Source	NaN deg	Whe	ere is it?	EXY *	Set
	Coordinate System		▶ When?	100000		
	Equinox Source	NaN yr	Clear local offsets	will it be?	Refraction	
	Limit Expected	Horizon Limit	Go	Moon F	lat Manual Override	False
	Limit Time Left	3.65 h	Stop	Unaraș Rol Unar	Air Temperature Value	0°C
	Moon Zenith Distance	61.89 deg	No. of Contract of		Barometric Pressure Value	0 mbar
	Sun Zenith Distance	77.69 deg	Tame		Humidity Value	0.%
	Telescope		Local Apparent Sidereal Time	18:48:46.944 h	Wavelength	0.6000 um
	Tracking In Tolerance	Out Of Tolerance	Modified Julian Day	57693.9759 MJD	Guiding Wavelength	NaN um
	Air Mass	2.3429	Julian Epoch	2016.8363 yr	Frank State Stat	
	Atitude	25.15 deg	TAI Minus UTC	36 s	Pointing Control	10-1 10 2 N 11
	Azimuth	179.23 deg	TT Minus TAI	32.1840 s	M1 and M2 Alighment Collimation	Faise Enable
	Hour Angle	-00:03:18.493 h	UT1 Minus UTC	-0.3238 s	Roller Encoders	False Enable
	Zenith Distance	64.8 deg	Orbital Element		Encoder Non-Linearity	False Enable
	Sun Separation	132.20 deg				
Alan	Moon Separation	47.44 deg	Source Orbital Element Scher		Pointing Corrections	
			Source Orbital Element Argur	And a second	Polar Motion X	0.1892 arcsec
	Space Motion		Source Orbital Element Daily Source Orbital Element Eccer	and the second	Polar Motion Y	0.2811 arcsec
Send	Source Space Motion Enabled	faise	Source Orbital Element Eccer Source Orbital Element Eccer	and a second	Collimation Correction Enal	bled False
Datum Tree	Source Parallax	NaN arcsec	Source Orbital Element Epoc		Collimation Correction Pitch	0 arcaec
File Operations	Source Proper Motion Epoch					

6. Please see the Using the LCOGT GUI and Moving the Telescope section for more information.

