Schulman Telescope StartUp Procedure

Check Internet

Go to the warm room closet and check that all internet cables are plugged in. There is one CAT5 cable that goes to the main observatory computer and another that goes directly to the telescope controller. During lightning shutdown these cables are often unplugged. While in the closet check to see that the StarDot video server is healthy.

Power up the Main Observatory Computer and UPS's

Plug in and turn on the small UPS that delivers power to the main computer and telescope services (including the TIM unit via the remotely controlled power outlets). Login to the main Windows user account. This is currently labeled "Adam" and the password is the standard "I8...." Next plug in and turn on the larger telescope controller UPS. The screen will turn on when you plug in the large UPS-however it is not yet delivering power. Follow the screen instructions and press the "power" button to start delivering power. (Do not turn on the controller yet.)

Interpret the Telescope Orientation and Clear Manual E-stops

Check the Telescope Orientation and assess the condition of the telescope. If the current position does not "make sense," consider investigating further before proceeding. If engaged, release any E-stops on the hand paddle, telescope controller, and dome controller. Although it should be in operable state by default, also check the upper shutter E-stop plunger by visual inspection. If this is inadvertently left pushed in it must be released or software shutter errors will follow. The key should be turned to the "on" position.

Check the RA Optical Tape and Read Heads

Before turning on the controller (or moving the telescope for normal operation) examine the RA axis optical tape for signs of water condensation or insect "residue." This must be cleaned before operation. Make certain both the drive and idler bearings are also free of anything that might be transferred to the optical tape. Look closely at the read heads and check to make certain they appear aligned without anything in the space between the read head and the tape. (Use a thin Tek wipe or something similar to clear the space and clean the window if necessary.)

Check the telescope Balance state

As of Fall 2016 the telescope is in a balanced state when the following conditions are met:

- 1. The CCD camera is attached to the back of the telescope. * (see note below)
- 2. There are no extra hardware or eyepieces attached to the telescope (e.g. No eyepieces should be installed in the refractor.)

3. The number of weights and configuration are as in the picture below:





4. **THE MIRROR COVERS ARE OPEN** This will be done shortly.

Note (Eyepieces)

The combination of the 31mm Nagler eyepiece and adapter at the back of the telescope is sufficiently close to "balanced" that it is OK to follow the startup process in this state. Being optimized for the CCD configuration permits better success at automation and recovery from errors.

Manually Point the Telescope to the Zenith

When on site for startup purposes it is OK to move the telescope against the Declination brake to point the telescope vertically (at the zenith on the meridian). This step is necessary as mountain operations currently (Fall 2016) requires the telescope be pointed "up" before opening the mirror covers. During a recovery event when the controller is one but the telescope needs to be re-homed, opening the mirror covers in other positions will still be OK. Even if the mirror covers do not fully deploy ("Mid Position")- the balanced state will be achieved and initializing the system can proceed. The mirror covers can then be closed and re-opened later.

Turn on the TIM Unit, Connect, and Open Mirror Covers

The TIM Unit must be turned on in order to open the mirror covers. Before turning it on make certain all connections are firmly seated into the enclosure. Turn the unit on with the rocker style toggle switch.

Next on the computer open the RCOS TIM software.





Connect to the TIM unit and navigate to the "Primary Mirror Covers" tab.

e Setting	s View I	Help								
		1					0			
isconnect	Record	Focuser	Rotator	Fan Te	emperatu	re Pri .	Mirror	Cover		
Primary M	irror Cover	Controller								1
Cover	1		Cov	er 2			1	Oper		
	03	≿ 1 mA			0%	0 mA		X Re	set	
	0	• i iiin			0%			• •••		
Cover	3		Cov	or A				Close	9	
Corei			CUV							
	02	% 1 mA	E		0%	1 mA				

Open the Mirror Covers:

connect Record Focuser	Rotator Fan Temperature Pri. Mirr	or Cover
Primary Mirror Cover Controller		
Cover 1	Cover 2	Open
0% 1 mA	0% 1 mA	X Reset
		Close
Cover 3	Cover 4	
0% 0 mA	0% 1 mA	

Turn On Telescope Controller

Turn the red switch to the "on" position. Fans and other noises will be heard as the system comes on. Wait for 3 minutes for the Mic and PubSub internal computers to boot. Generally when the MIC completes booting the drives/servos are alive and holding the telescope (listen for them).



Connect to the PubSub Machine using VNC

Open VNC and type the address to PubSub shown below:

V2 VNC Viewer		-	
VNC® Vie	wer		Ve
VNC Server:	lune.as.arizona.edu:4260		~
Encryption:	Let VNC Server choose		~
About	Options]	Connect

(It is assumed the user has the password.)

Initially the desktop will be blank (black). Start PubSub processes by pressing the tool utility icon at the top of desktop. It is circled in the image below:



This will clear the database and give everything a clean start. Eventually (a few minutes) the "JADE" agent will load and the desktop will look like the below:



The small icons to the right of processes can be pressed to expand them and reveal the list as shown. Once the "Instruments-xx01_0m8a_doma" process is loaded under its section PubSub is ready to communicate with the telescope (and the user). The "RPC_Gateway" process will not show up until communication to PubSub through the web browser commences. This is in the next step. It is OK to close the VNC window.

Access the LCOGT GUI

Now that the system is up and running with drives, servos, and PubSub- access the LCOGT GUI:

1. Open the Chrome Browser and click the quick link labeled PubSub (leftmost icon). You will be presented with the screen below:



The log on name is unimportant. However *default* is required for the Config File field.
Press the "OK" button to continue.

- 2. Wait for PubSub to send all of the data to the browser. It will take 2-4 minutes. If you simply have a blank/white screen → going back to PubSub through VNC may be necessary to make certain it is setup correctly.
- 3. Once the GUI comes up you will be presented with the Site heads up information. Note the small tab is labeled "tus." This stands for "Tucson." None of the capabilities on this screen are currently in use.

W when Editoreau Change	NebRelays 11 Power Outlets (Remain Ph Skycer	nter Trouble Re	Mt Lemmon SkyCent		Obsence 🐘 Satellite name: RAP Re	SDO I Solar Dynamic
Tools	R Lus				TUS	Alive 2016-1	1-01 23:20:49
Chat (Alan)	doma						18:44:1
	Weather Site Boltwood	d Thresholds A	ctivity Config	Harvest Reduction Services	Power		
	Agent State			Overrides		Infrastructure	
	Weather	Okay		Cloud Override	False	Sems Version	
				Sun Override	False	Panel Temp	0 °C
	Weather Control				10	Battery Voltage	0 V
		Overrides	-	Values		Last Reading	
	Ci000	Enable	Disable	Air Temp	0.0 °C	Watchdog Errors	0
	Sun	Erlable	Disable	Barometric Pressure	0.0 mbar	Weather System Type	DUMMY
	Countdown to Open		Reset	Dew Point	0.0 °C	Weather System Url	
	Limits One			Electric Field	0 V/m		
	Ok To Open	Enino		Humidity	0 %	Moon	
	Countriaum To Onco	Parse		Weather Leaf Sensor Voltage	e Val0 mV	Topocentric Right Ascension	16:11:02.796 h
	Countdown to Open	0 sec		SQM Sky Brightness	0.00 mag/arcsec^2	Topocentric Declination	-16:40:53.857 deg
	Thenock Reason	Sun Op		Solar Insolation	0 W/m/m	Zenith Distance	61.29 deg
	Inreshold Class			Wind Direction	0 deg	Azimuth	222.61 deg
	Limits Two			Wind Direction Avg	0 deg	Angular Diameter	0.49 deg
	Oh To Ohun	Taba		Wind Speed	0.00 m/s	Illumination Fraction	0.044
	Ok 10 Open	Faise		Wind Peak 12 seconds	0.00 m/s		
	Countdown To Open	0 sec		Wind Peak 10 minutes	0.00 m/s	Sun	
	Interlock Reason	Sun Up		Weather Rain Alert	Clear	Topocentric Right Ascension	14:30:14.616 h
	I nresnoid Class	1		Particulates (1 micron)	0 parts/m^3	Topocentric Declination	-14:48:12.161 deg
	Limits Three			Boltwood Transparency Aver	age NaN %	Zenith Distance	76.89 deg
	Ok To Open	Enico		Boltwood Sky Minus Ambient	Av NaN *C	Azimuth	242.68 deg
	Countriown To Occor	0 sec				Angular Diameter	0.54 deg
	Listorlock Passon	Cup Lip		Failures		Morning Astronomical Twilight	12:17:44.304 h
	Threahold Class	I SUN UP		Battery State		Morning Civil Twilight	13:15:31.680 h
	I freshold Class			Electric Field Sensor State		Sunrise	13:40:55.524 h
	All Sky Camera			Humidity Sensor State		Sunset	00:33:00.972 h
Alan				Leaf Sensor State		Evening Civil Twilight	00:58:21.720 h
Alan	an allebra			Particulate Sensor State		Evening Astronomical Twilight	01:56:04.272 h
	no alisky d	camera av		Pressure Sensor State			
Send				Rain Sensor State		Sky	
atum Tree	F			Sky Brightness Sensor State		Illumination	18150.0541 lux
e Operations	÷.			Solar Sensor State		Brightness Ratio	9075027.07

4. Click on the tab beneath "tus" to expose the information under the "doma" tab. The LCOGT software can be used to control multiple telescopes at a site. Our single site has a single telescope in the "A" dome which is roughly "doma." Again this functionality is not being used.

Apps R PUBSU	B! 🏱 APS: Web	Relays 🍙 Pow	er Outlet	s (Remotine 🏱 🖞	Skycenter Trouble Re:	Mt. Lemmon SkyCent	HANDOUTS	Mt. Lemmon Observ	Satellite	e page: RAP Re 📓 SDO Solar Dynamics
Tools Chat (Alan)	र ह	tus doma					_	TUS	Alive	2016-11-01 23:21:19 18:44:49
		Om8a							_	
		Enclosure Contr	ol Fac	lity Services po	ower Observatory (Config Dome Telemetry				
		Agent State				Shutters			Services	
		[not available]	1	[not a	vailable]	[not available]	(not avail	able]	[not available]	[not available]
						[not available]	(not avail	able]	[not available]	[not available]
		Enclosure				[not available]	[not avail	able]	[not available]	[not available]
		-	0000	Shutter Contro	4	[not available]	(not avail	able]	[not available]	[not available]
			Noso	Both		[not available]	[not avail	able]	[not available]	[not available]
			1050	Ston		[not available]	(not avail	able]	[not available]	[not available]
		Clea	ar Faults	Citop	Reset PLC	[not available]	(not avail	able]	(not available)	[not available]
		Simu	ulate On		Simulate Of	[not available]	(not avail	able]	[not available]	[not available]
						[not available]	(not avail	able)	[not available]	[not available]
			Plow	Azimuth Contro	Rob	[not available]	[not avail	able]	[not available]	[not available]
			Supe		dog	[not available]	[not avail	able]	[not available]	[not available]
			bynic t Deck		deg	[not available]	[not avail	able]	[not available]	[not available]
		Se	et Park		lises	[not available]	[not avail	able]	[not available]	[not available]
			Park		Home Stee Deest	[not available]	[not avail	able]	[not available]	[not available]
			Stop.		Close Foults	[not available]	[not avail	able]	[not available]	[not available]
		Simi	ulate On		Simulate Off	[not available]	[not avail	able]	[not available]	[not available]
		Slave	c c	aund: Innt aug	Clauged To: Inct avails	in Freeman			[not available]	[not available]
		0m8a	•	On	Off	foot available!	(pot ovoil	abial	Vititude	
						[not available]	(not avail	able	fast available!	feet eventering
				Agent		[not available]	[not avail	able]	[not available]	[not available]
		-		TYUJUT		[not available]	[not avail	ablel	Nebcam (wcama.	doma.tus.lco.gtn)
		Links		Building	01	[not available]	(not avail	ablel		
		Lights		On	Uff	[not available]	(not avail	ablel		
				Overrides	I mouth	[not available]	(not avail	ablel		
		Weather	-	Enable	Disable	[not available]	[not avail	ablel		
	Alan	Power	-	Enable	Lisable	[not available]	(not avail	ablel		
	Han	Апонар	-	Reset	[not available]	(not available)	(not avail	able]		
						[not available]	(not avail	able]		
	Send					[not available]	[not avail	able]		
Datum Tree						[not available]	(not avail	able]		
File Operations	6.4					fast supjected	Inst aug	inhial		

5. Finally click on the "0m8a" tab to expose the controls for the Schulman Telescope. This tab roughly translates to 0.8m a (or first 0.8m telescope).

Last update: 2019/06/07 public:catalinas:lemmon:schulman_32:schulman_telescope_startup_procedure https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:lemmon:schulman_32:schulman_telescope_startup_procedure&rev=15599342 12:03
--

		ing the second	Der versten	• · · · · · · · · ·			
III Apps [20] PUBSUB	B! [] APS: We	bRelays [] Power Outlets (R	emo: 📋 Skycenter Trouble Re; 🛛	Mt. Lemmon SkyCent] HANDOUTS 🔜 Mt. Lemmon	Observa 🧐 Satellite page:	RAP Re SDO Solar Dynamics
Tools	रर	tus			TUS	Alive 20	16-11-01 23:21:41
Chat (Alan)	E	0-0-					18:45:10
		uma-a					
		+ State Observation Script	Sequencer Source Tracking	Axes Guide Instrument	Ins View Spectrograph Calibr	ste Focus Optical Tube	Telescope Services 1 Telescope Services
		Tracking		Description		Behaviours	
				Mount Type	1	Astrometric	122
		Disable Roll Di	sable Pitch Enable Rotator	Inform Type	P	Inot available1	Inot available!
		Stop	Tracking Loop	Current Message Queue Siz	*	(not available)	(not available)
		Rotator Mode		Astrometric	0	Config	18
		Laky .	set	[not available]	[not available]	InstrumentSelector	22
		Other States		Axes	0	Monitor	9
		Actrometric Kernel Ciele	Clanned	Config	0	[not available]	[not available]
		Astromatric	Okay	InstrumentSelector	0	Paddle	31
		Inot available!	Inot available!	Monitor	0	SdbAgent	10
		Container State	Okay	[not available]	(not available)	[not available]	[not available]
		Agent Count	10	Paddle	0	[not available]	[not available]
				SdbAgent	0	(not available)	[not available]
		State		[not available]	[not available]		
		Astrometric	Okay	[not available]	[not available]	Software Repository Path	
		(not available)	[not available]	[not available]	[not available]	Astrometric	issue-5613-2
		Mount	Okay	Software Revision		[not available]	[not available]
		Mount State	Okay		Transie	Axes	issue-5613-2
		Config	Okay	Astrometric	3b4d9fe	Config	issue-5613-2
		InstrumentSelector	Okay	[not available]	[hot available]	InstrumentSelector	issue-5613-2
		Monitor	Okay	Axes	3b4d9fe	Monitor	issue-5613-2
		[not available]	(not available)	Contig	3040910	[not available]	[not available]
		Paddle	Okay	Monitor	3040910	Paddle	ISSUE-5613-2
		SdbAgent	Okay	feet available)	[oot ovoilable]	SabAgent	Issue-6613-2
		[not available]	[not available]	[not avanable]	ab4dofe	[not available]	[not available]
		[not available]	[not available]	Sdbådent	3h4d9fe	[not available]	[not available]
1	Alan	TestAgent	OKay	[not available]	Inot available	[interavanable]	[inst available]
	Alan	[not available]	[not available]	[not available]	[not available]		
		Instrument State		[not available]	[not available]		
	Send	xx01	Oray	(Januar Station of Station			
Datum Tree	5	Agent Alive Time	67344 s				
File Operations	1	A A 2011 VALLE 1 HUE	0.044.0				

6. Take note of the color of the fields in the column on the left in the above image. They should all be green when the telescope is ready to be used. The "astrometric kernal" can be "yellow" when the drives are not tracking. If the telescope is tracking, this will also be green. If you come to this tab/screen quickly after rebooting PubSub, you may see fields such as "Mount State" indicate "initializing." This is OK provided that the agent does eventually initialize the drives and the field goes to green after a minute or two.

Homing the Schulman Telescope

The telescope must be homed before it can be operated.

1. Go to the *Axes* tab. Note that the axes are **Unhomed**.

Mount						
ves Command		Okay			11 12 43	
wes commany			aus	sena (@ 2010	11-10.02	
Age	ent Enable		A	gent Disable		
Roll		Pitch		lotator		
Standby		Standby		Off		
Unhomed		Linhomed		INKNOWN		
Pos Vel		Pos Vel		Pos Ovel		
0.0	deg	0.0	deg	0.0		
Slew		Slew		Sle	W	
Halt		Halt		Halt		
Home		Home		Hon	ne	
Park		Park		Pa	ĸ	
Unwrap		Unwrap		Unwrap		
Stop		Stop		Stop		
Stop Res	et	Stop Reset		Stop Reset		
Enable		Enable		Enable		
Disable		Disable		Disable		
Goto Pos	L1	Goto Pos L1		Goto Pos L1		
Goto Neg	L1	Goto Neg L1		Goto N	eg L1	
Recover l	.2	Recover L2		Recov	er L2	
Fault Res	et	Fault Reset		Fault F	leset	
		Slew				
		Halt				
		Park				
		Home				
		Stop				

2. Press the large HOME button (circled below) to move both axes simultaneously to the home position. See Telescope Orientation for the correct position.



3. Once homed successfully the state field will briefly go to "stopped" and then finally "L1 Positive Limit" in both axes:

lgent State								
Mount	Okay							
Axes Command								
Agent Enable	1	Agent Disable						
Roll	Pitch	Rotator						
Okay	Okay	Off						
Haltod I 1 Dositivo I imit	Halted I 1 Decitive Limit	LINKNOWN						
Pos Vel	Pos Vel	Pos Ovel						
0.0 deg	0.0 deg	0.0 de						
Slew	Slew	Slew						
Halt	Halt	Halt						
Home	Home	Home						
Park	Park	Park						
Unwrap	Unwrap	Unwrab						
Stop	Stop	Stop						
Stop Reset	Stop Reset	Stop Reset						
Enable	Enable	Enable						
Disable	Disable	Disable						
Goto Pos L1	Goto Pos L1	Goto Pos L1						
Goto Neg L1	Goto Neg L1	Goto Neg L1						
Recover L2	Recover L2	Recover L2						
Fault Reset	Fault Reset	Fault Reset						
	Slew							
	Halt							
	Park							
	Home							
	Stop							

4. Now go to the *Source* tab and move the telescope out of the limits to a valid sky position. If the telescope is not going to be used immediately typically the telescope is sent to the park position. Remember to stop the tracking loop if observing is not going to start. The zenith position is inputted in the picture below.

1.

	abRalaur B Rowar Outlate (Ramo	Ph. Slovcenter Trouble Rev.	Mt Lemmon SlotCent		Mt Lemmon Ob	anus 🧑 Satallita paga: RAD R		knamic
APS: W	Power Outlets (Renio		With Certification Skycenia [With Lemmon Cos	Satellite page: KAP h	500 Solar D	ynamic
ools 🕅	doma				TUS	Alive 2016-	11-01 23:2	5:14
ne (nen)	0m8a						10.	40.40
	+ State Observation Script	Sequencer Source Tracking	Aves Guide Instrument	Ins View 1	Spectmoraph Calibrate	Encus Ontical Tube Talass	one Services 1	soone Se
	Francesco	dahari dikindili						
	Agent State		Source Selection			Retraction		l.
	Astrometric	СКау	Astrometric Kernel State:	Stopped		Pressure:		mba
	Point		Known objects:		• Go	Humidity:		%
	Point/Next St	art End				Temperature.	Override	-0
	Skip Sti	ore Clear	Source Name:	none	Fetch Clear	Clear	Override	
	Goto nearest pointing s	star Clear local offsets	Coordinates		-	Cita	oreinde	
	C.		Hour Angle:	0	h h	Tracking		
	Source		Declination:	32	den			
	Name		Engen Motion		ada	Disable Roll Disa	ble Pitch Enab	
	Right Ascension Source	NaN h	Orbital Elements			Rotator Mode	аскілд Loop	
	Declination Source	NaN deg		Where is it?		SKY Y		
	Coordinate System		▶ When?					
	Equinox Source	NaN yr	W	here will it be?		Refraction		
	Limit Expected	Horizon Limit	Clear local offsets	Mo	n Flat	Manual Override	False	
	Limit Time Left	3.65 h	Stop	Unwran	Roll Unwap Rot	Air Temperature Value	0 °C	
	Moon Zenith Distance	61.89 deg				Barometric Pressure Value	0 mbar	
	Sun Zenith Distance	77.69 deg	Time			Humidity Value	0 %	
	Telescope		Local Apparent Sidereal	Time 18:48:4	46.944 h	Wavelength	0.6000 um	
			Modified Julian Day	57693.	9759 MJD	Guiding Wavelength	NaN um	
	Air Mose	Out Of Tolerance	Julian Epoch	2016.8	363 yr			
	Althude	2.3429	TAI Minus UTC	36 s		Pointing Control		
	Attoute	170.32 deg	TT Minus TAI	32.184	0 s	M1 and M2 Alignment	False	Enable
	Hour Angle	-00-02-18-402 h	UT1 Minus UTC	-0.323	Bs	Roller Encoders	Faise	Enable
	Zenith Distance	64 8 dec	-			Encoder Non-Linearity	False	Enable
	Sun Senaration	132 20 den	Orbital Element			Encoder NorPLinearity	- shat	Linada
Alan	Moon Separation	47.44 dep	Source Orbital Element S	icheme		Pointing Corrections		_
	Involte population	1-1-1-008	Source Orbital Element A	vgumer NaN d	eg	Polar Motion X	0.1892 arcsec	
	Space Motion		Source Orbital Element D	ally Mo NaN de	eg	Polar Motion Y	0.2811 arcsec	
Cand	Source Space Motion Enabled	false	Source Orbital Element E	ccentric NaN		Collimation Correction Enable	ed False	
Denta			III Cource Orbital Element E	noch OlNaN M	UD		and the second se	
um Tree	Source Parallax	NaN arcsec	Source Orbital Element E	pour of vary in		Collimation Correction Pitch	0 arcsec	

6. Please see the Using the LCOGT GUI and Moving the Telescope section for more information.

