Normal Start Up

1. Plug in the twist lock AC power cable to the dome shutter motor on the west wall.
2. Switch "dome power" to the ON position at the telescope power box (middle black button).
3. Open the shutter using the shutter control box on the south wall. Keep hand ready to hit STOP button until fully open.
4. Switch "telescope power" on at telescope power box.
5. Unplug shutter motor on the west wall (or dome won't move).
6. Power on TCS console/GUI computer under table.
7. Login "21inch", password - leave blank, hit enter.
8. Switch "telescope control" to remote on the telescope power box.
9. Open the mirror covers using the handles on the side of the telescope. [1]
10. Start TCS GUI. Double click icon "TCS GUI 03-24-2008".
11. Click ENABLE (comes up green, turns red when clicked)
12. See instructions on telescope initialization, then start observing.

NOTES:

To stop telescope motion hit STOP (in red)

Dome Stow Position - center of dome over eastern wheel above entry door.

[1]
Open the south side first.