Normal Shutdown

1. Stow the telescope. In the TCS GUI click on the "Service" tab. Click "Stow" then click the "GOTO" button directly below "RELOAD".
2. Close the telescope mirror covers (in the correct order - north first, then south)
3. Stow the dome. Use the hand paddle to center the shutter over the eastern dome rotation wheel above the main entry door to the dome.
4. Plug in shutter motor
5. Close shutter using shutter control box.
6. Shutdown TCS using "X" in upper right of GUI.
7. Shutdown TCS gui computer.
8. Turn off power to telescope drives at the Telescope power box
9. Switch dome control to local at the telescope power box.