

AzCam Load Controller File Error

When resetting AzCam, you may see **LoadControllerFile error** in the AzCam status window. To fix this follow these steps:

- Quit out of AzCam
- Doubleclick Restart Camera Server on the desktop
- Start AzCam

The issue should be fixed. If not, repeat.

From:

<https://lavinia.as.arizona.edu/~tscopewiki/> - MOON

Permanent link:

https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:bigelow:kuiper_61:troubleshooting:azcam_load_controller_file_error&rev=1567551760

Last update: 2019/09/03 16:02

