

# If the displays are powered off or showing a white error page:

## Check the Intel NUC

- \* Make sure the Intel NUC (a small black computer in the UPS closet) is powered on.
- \* Wait at least 2 minutes after powering it on, as it takes time to load the web server.

## Check the Raspberry Pi units

- \* Plug in the two Raspberry Pis labeled telemetry and weather.
- \* Each Pi will automatically launch a web browser in full-screen mode and load the correct URL.

From:

<https://lavinia.as.arizona.edu/~tscopewiki/> - **MOON**

Permanent link:

[https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:bigelow:kuiper\\_61:troubleshooting:telemetry\\_weather\\_display](https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:bigelow:kuiper_61:troubleshooting:telemetry_weather_display)

Last update: 2025/05/20 16:32

