Last Updated: 04/22/2019

Cold Start Power Up Sequence

Procedure for coming out of lightning shutdown or checking out the telescope and instrument.

Dome Part 1

1. Dome encoder cable over entry door

West side of blue yoke, declination axis

- 1. Dec encoder
- 2. Dec motor
- 3. Dec tac

West side of base flange

1. Finder scope lamp power (for reticle)

East side of base flange

- 1. Limit cable
- 2. Index sensor cable

Inside the south pier

- 1. From outlet box #5
 - 1. Power cord running to power strip inside blue rack
 - 2. Power cord running to power strip mounted to south pier
 - 3. Power cord running to index meter box
- 2. Black rectangle cable connection laying inside
 - 1. NOTE: Two cables plugged into one another that have black connectors
- 3. Index meter cable
 - 1. NOTE: Connects up underneath backside of index meter box

RA Axis

- 1. RA encoder on west side
- 2. RA motor cable on east side
- 3. RA tachometer cable on east side

Last update: 2019/06/07 11:15 11:15

Backside of blue rack

- 1. Silver outlet box
 - 1. Mux power plug
 - 2. Bus extender cable
 - 3. Bus BNC
- 2. Bus extender
 - 1. Bus cable
 - 1. NOTE: There is a black screw keeping cable in place.
- 3. Backside of dome box
 - 1. #4 paddle
 - 2. #2 bus extender cable
 - 3. Dome encoder
 - 4. DEC encoder cable
 - 5. RA encoder cable
- 4. Backside of stepper box
 - 1. Gate out BNC

Control Room

Backside of blue control rack

- 1. Bottom of rack
 - 1. #5 TTL mono dome
 - 2. #3 stepper motor control
 - 3. #2 computer manual to dome and telescope control
 - 4. #1 single paddle control to old paddle
- 2. FORTH computer backside
 - 1. NOTE: If 2MASS is on the telescope there is nothing to disconnect. If another instrument is on the telescope then disconnect Com2 cable.
- 3. Silver outlet box
 - 1. Bus BNC
 - 2. Power supply cable
 - 3. Power supply cable

Backside of rack #1

- 1. PC splitter box
 - 1. "From dome" silver cable
- 2. Video monitor
 - 1. Video input BNC cable
- 3. TV offset guide control backside
 - 1. Round connector
- 4. Focus panel backside
 - 1. Focus cable on left hand side

- 1. NOTE: Easy to miss
- 5. Chop box
 - 1. Large round connector cable
 - 2. Transducer BNC

Backside of rack #2

- 1. RA motor round connector
- Temperature sensor square gray plug
 NOTE: Easy to miss

Backside of rack #3

- 1. DEC motor cable
- 2. Master Control Panel backside
 - 1. Slew SW BNC far left
 - 2. J12 under cccc to the right
- 3. Telescope drive control backside
 - 1. Limit cable p8
 - 2. #5 TDC cable
 - 3. Tilt meter cable
 - 1. NOTE: Easy to miss, just under DEC preamp
 - 4. #5 DEC preamp
 - 5. #7 RA preamp

Front of blue control panel

1. Ribbon cable from port 5 to 5

Front of rack #1

1. Microphone connection for dome

Behind control console

- 1. Plug two calbes running into ceiling
- 2. Plug power strip and UPS laying on the floor into the wall outlet
- 3. Plug two ethernets

Dome Part 2

2MASS

- 1. Plug in UPS into wall outlet.
- 2. Turn on UPS.
- 3. Plug in orange extension cord into UPS
- 4. Remove the cover form temperature control port.
- 5. While wearing a grounding strap, connect temperature controller cable.
- 6. Plug in temperature controller unit into UPS.
 - 1. NOTE: Sits on blue rack
- 7. Plug in the Controller square gray power supply into power strip at base of telescope.
- 8. Plug in the IR Camera Power silver box into power strip at base of telescope.
- 9. Turn on Controller power supply
- 10. Turn on IR Camera power supply

Follow the instructions in the black binder to finish setup.

From: https://lavinia.as.arizona.edu/~tscopewiki/ - MOON

Permanent link: https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:lemmon:minnesota_60:cold_start_power_up_ Last update: 2019/06/07 11:15

