

- Make absolutely certain that 🚨 Derotator tracking is disabled 🚨 **Fix Me!** To turn off, click on the Derotator field, click on the derotator position field, opening a small dialog box, toggle the tracking there, wait for TCS to react (status “Derotator tracking is off” in the Derotator field), and close the dialog box.

From:

<https://lavinia.as.arizona.edu/~tscopewiki/> - **MOON**

Permanent link:

https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=vatt:operating_pepsi&rev=1718142122

Last update: **2024/06/11 14:42**

