

	<b>Lightning Startup / Jul 9, 2021 / M Franz, P Gabor, D Brown</b>	✓ X
	In this scenario, the (simplified) lightning shutdown condition (see <a href="#">vatt_lightning_shutdown_checklist</a> ) has <b>one</b> AC-power breaker turned OFF or OPEN. This is the 100A breaker in Panel A (1st level) that feeds Panel C (TCS room).	
	<b>These actions take place on the VATT's building level 2</b>	
Instrument room	Plug in both twistlocks for the computer racks	
TCS room	Raceway quads: ↓	
	Left quad (UPS power): receives two plugs only: vatttel and mirror air support	
	Right quad (conditioned power): receives three plugs: servos, cell fans, and fiber media converter	
TCS room	GPS antenna connector: screw it into the back of the GPS unit	
TCS room	Turn GPS unit ON. It will not come on at this point but it takes a long time to finish its power-up sequence, and if it is plugged in early, it will start this sequence as soon as the UPS power is restored, shortening the wait until vatttel can be booted.	
	<b>These actions take place on VATT's building level 1</b>	
Loading dock	Plug the 4kVA UPS output 220V plug into the receptacle in the rear of the UPS	
Loading dock	Plug the 4kVA UPS input 220V plug into the wall receptacle	
Telecom room	Close (turn on) the 100A breaker in Panel A (the triple breaker is labeled Panel C)	
Loading dock	Turn on the 4kVA UPS unit, turning the key on the front panel. Check that it is Ready and probably Charging	
	<b>These actions take place back on the VATT's building level 2</b>	
Instrument room	Power up the two UPS units at the bottom of the right rack by holding down the power button on each until an audible signal (beep) is heard, then release the button	
Instrument room	After the fans have finished spinning up, press the power button on the KVM auxiliary monitor (above the vattarchive server). ↓	
	After FREE flag is displayed, indicating the KVM is finished booting, press the Page Down key (empty server-selector window will appear)	
Instrument room	Power up vattdata: Momentarily press down the power button. (There are three LEDs on the right of the server front panel. The top one is amber, the lower two are off. The top one is also the power button. Release the top one when, all three turn green.)	
	KVM: vattdata should appear in the server-selector; its indicator should turn green	
	More help on the KVM is available in <a href="#">Miscellaneous Tips</a>	
	KVM: Connect to vattdata (using the up/down scroll keys or the trackpad; hit Enter)	
	KVM connected to vattdata: Boot sequence for vattdata is displayed. When complete, the screen should have the appearance of a text terminal. The contents should stop scrolling and an ASCII list of 12 items should appear. If the computer is left unattended for a long time after it is booted, some error messages may appear under the list. Ignore them. If it has been an extremely long time, the error messages may take up the whole screen. If that is the case, hit Enter and the list of 12 items will reappear.	

	<b>Lightning Startup / Jul 9, 2021 / M Franz, P Gabor, D Brown</b>	✓ X
Instrument room	Power up all the rest of the servers: ↓	
	Make sure vattdata is fully booted (takes approx. 10 mins) before you proceed to the other servers	
	Power up vattcontrol, vattiraf, vattdev, vattarchive, vattccda, and PEPSI	
	<i>Note. vattiraf, vattccda and vattdev are not needed for PEPSI runs, while PEPSI is not needed for VATT4k runs and vattccda is not needed for GUF runs. It is our policy, however, to boot <b>all</b> the servers up because bad things happen if servers are left powered down for months; so we err on the side of prudence and always power them all up. What is more, certain servers may be used by our colleagues remotely (including computer support). vattdev, in particular, is useful because it is the portal through which the port-forwarded access to other machines is served to the outside world.</i>	
TCS room	Check that GPS is fully live: two steady blue lights: Power (right) and Ready (center)	
	If not, wait until it is	
TCS room	Boot vatttel (first, turn on the monitor above the rack): (Re)Booting VATTtel	
	Check that it is fully booted. Ignore the error complaining that the guider is "screwed up".	
	Turn the monitor off	
	<b>Proceed to the <a href="#">vatt_warm_startup_checklist</a></b>	

From:  
<https://lavinia.as.arizona.edu/~tscopewiki/> - MOON

Permanent link:  
[https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=vatt:vatt\\_lightning\\_startup\\_checklist&rev=1625893637](https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=vatt:vatt_lightning_startup_checklist&rev=1625893637)

Last update: 2021/07/09 22:07

