
2025/04/08 13:56



General principle



Comments & suggestions welcome

Dome floodlights

Up The dome fluorescent lights are operated by an inconveniently placed switch. Avoid finding yourself walking in the dark. Use the dome floodlights operated from the control room. Prior to leaving the control room for the dome, turn on the dome floodlights (switch to the left of the door to the SW porch off the control room).

Cameras

4 At all times, take advantage of the Hikvision and Axis cameras in order to monitor the status of the telescope. Dome, Security & Finderscope Cameras

Porch doors

Use It is only too easy to lock oneself out when stepping onto the SW porch off the control room and the W landing off the dome. Do not panic if you do. Climb down the ladder and circle around to front door of the building.

From

https://lavinia.as.arizona.edu/~tscopewiki/ - MOON

Permanent link:

 $https://lavinia.as.arizona.edu/\sim tscopewiki/doku.php?id=vatt:vatt_operations_readme\&rev=1718140663$

Last update: 2024/06/11 14:17

