Normal Operating Instructions for the Schulman 0.8m Telescope

In this case "normal" basically means using the telescope for visual observing (SkyNights programs).

Everything that follows assumes the following:

- Telescope Controller is operational and in the normal state. (Telescope servos are on and the telescope has been homed. The telescope is in the ready state to observe.)
- Dome is operational and in the normal state.
- Computer does not have other running software, scripts or connections that would interfere with normal operations.


Starting things up

1. Open ACP (see desktop Layout) Under Telescope menu select Connect.

ACP T	elescope Camera Ro	tator Weather Help	
LS	Connect	EV BEM POT	
RA	Park	CUS DOME WEA	Select the Script
De	Unpark	ACK GUIDE ENP	Click Browse to select the script to ru Most often this will be AcquireImages
Az	Set Time	Display Hour Angle	
Alt	Set Location	Display J2000	_
UT	Load Model	-Nov-16 Console of	si trout-
	Save Model As	Sidereal Tracking	
[Ro	Setup	b Access	
0.855.55	osition Angle:	Uper:	
S	et Angle 000.0	Status: Available	
		Ovnet:	
Slev	w or Sync (catalog)	Use Web Browser	,
N	udge Telescope	Dome Control	Abort Alert Flur


- 2. Upon connecting the heads up screen will show the coordinates of the telescope. Please verify LST and coordinates make sense.
- 3. If ACP complains the COM port is not available, it is likely another program is talking to the DOME or Telescope controllers. (e.g. ASCOM Dome software)
- 4. Also ACP is set up to command the dome to find **HOME** when first connecting. If ACP was already connected to the telescope and the dome is slaved the dome will not move.
- 2. Press the "Dome Control" button to reveal the dome state. It will only allow this once the dome is homed and not moving.

Last update: 2016/11/04 normal_operating_instructions https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=normal_operating_instructions&rev=1478312183 19:16



Seeing *Slaved* and reporting the correct Azimuth is a success.

- 3. Open the dome by pressing the "Open" button.
- 4. After the shutter is open move the telescope to the Zenith position (in order to open the mirror covers). Once there the telescope is now tracking.
 - 1. Press the *Slew or Synch (Catalog)* button to command the telescope to move.
 - 2. Select to radio button for *Coordinates* and input LST values for the RA coordinates and 32 for Declination.




3/7


3. Press the Go To button to slew to Zenith.

5. Open the RCOS TIM software and *Connect*.

Last update: 2016/11/04 normal_operating_instructions https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=normal_operating_instructions&rev=1478312183 19:16




- 6. OPEN the Mirror Covers.
- 7. Press the *FOCUSER* icon to be certain the secondary mirror is at the Eyepiece focus position.



If not at eyepiece value, select this position and press the green check mark.

8. Using ACP *Slew or Synch*, command the the telescope to point at a first object. This is typically a bright star to verify pointing.

Last update: 2016/11/04 normal_operating_instructions https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=normal_operating_instructions&rev=1478312183 19:16




(See "Can not find bright star" wiki page for troubleshooting information)

The telescope is now ready to start observing. Below are more important things to know:

 In ACP Slew or Synch → Deep Sky Object you must put a space between the catalog and its number. For example, "M77" will not work but "M 77" is correct.





7/7

• When necessary use the telescope Hand Paddle to center objects.

