# **Focus Positions and Mounting**

In this document will be the current focus positions and configurations for cameras and eyepieces on the Schulman Telescope.

## Mounting

Our camera and eyepiece focuser are mounted directly to the telescope rotator and fastened with 4 thumb screws. These screws should be placed ever 3 positions along the bracket.

# Main Camera (SBIG AC4040BSI)

### **Focus Position**

Our main camera uses [] and [] in spacers from the mounting point and achieves focus just around **32000** counts in the FocusPro.

## Focuser (FeatherTouch)

### **Focus Positions**

The focuser with most of the time be used with just eyepieces but, on occasion, other instruments and cameras may want to be installed. As such this section provides guidance on as many of these options as possible.

#### Eyepieces

The Focuser uses no spacers (reconfigurable spacers that is) from the mounting point and achieves focus at **70,000** counts in FocusPro. The position of 25,000 was selected so focus is right at the middle of travel on the FeatherTouch focuser using a TeleVue 31mm eyepiece.

# NOTE: Focus is only achieved at 70,000 when both the diagonal AND rotator ring are attached

#### DSLR

To use a DSLR (Canon, Nikon, Sony) can be attached with their respective adapters with a few focuser changes. First, the Eyepiece and Diagonal must be removed. NOT the rotating thingy, just the diagonal. Once that is removed change the focus position to ~~~ counts and you should be very close to focus.

Last update: 2023/08/24 public:catalinas:lemmon:schulman\_32:focus\_positions https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:lemmon:schulman\_32:focus\_positions&rev=1692901462 11:24

#### Planetary Camera (ZWO with ADC)

To use a Planetary camera, specifically our ZWO ASI183MC with ADC, remove the diagonal from the telescope (just like with a DSLR) and attach directly using the 2in adapter that is already mounted to the Planetary Camera. The camera will focus around  $\sim \sim \sim$  counts.

## Other

