2025/11/28 15:25 1/3 PHD2 Guiding

PHD2 Guiding

C. Johnson

3/16/2018

updated Oct 3, 2018 by P Gabor & C Johnson

All of the required software is currently installed on the vattcontrol server; login as vattobs.


The legacy *VATT Guider App*only controls the stepper motors in the guide box.* Guiding is done with *PHD2*!

- (*) When using VATT4k and GUFI, these motors move the two filter wheels for the science camera, the guider camera's filter wheel, the guider camera's 3-axis translation stage, and the stage carrying the center mirror and the U mirror.
 - start indiserver
 - click the indiserver icon on the desktop
 - (a terminal window should appear)
 - start phd2 guiding
 - click the PHD2 icon on the desktop
 - (the PHD2 application should appear)
 - configure phd2
 - 1. in the Main tool bar, click icon that looks like a usb male connector
 - (connect equipment window should appear)
 - 2. in connect equipment window verify the following settings:
 - equipment profile "vatt imagers" or "vatt spec" depending on your instrument (the imagers are 4k CCD and GUFI),
 - 3. in connect equipment window, in the camera row, click on the icon that looks like a screwdriver and wrench in an "X"
 - (INDI Configuration window should appear)
 - 4. in INDI Configuration window click the INDI button near the bottom of the window
 - (INDI options window should appear)
 - 5. select the Apogee CCD tab
 - 6. verify the following settings:
 - in the network section:
 - offset guider (used with imagers) ip:port : 10.0.3.14:2571; slit plate guider (used with VATTspec): 10.0.3.12:2571

- 7. click the connect button in the Connection field
 - (after a few seconds, a bunch of new fields and tabs should appear.)
- 8. near the bottom of the window, turn on the cooler
- 9. IF YOU ARE GOING TO BE AUTOGUIDING:
 - click on the "INDI-VATT-GUIDE" TAB
 - click "Connect"
 - (a UT clock should appear and begin incrementing.)
- 10. exit the INDI options window
- 11. click OK in the INDI Configuration window
- 12. click Connect in the Connect Equipment window, in the camera section
 - (the button should now say Disconnect)
- 13. IF YOU ARE GOING TO BE AUTOGUIDING:
 - click Connect in the Connect Equipment window, in the mount section
 - (the button should now say Disconnect)
- 14. click Close in the Connect Equipment window
- 15. In the Main tool bar (it may be positioned anywhere in the window),
 - click the Advanced setup (brain icon) button (second from the right); a new window should appear.
- 16. Set binning to the allowed maximum of 8×8:
 - Select the Camera tab,
 - in the group Camera-specific properties, set binning to 8 (pull down selector).
 - [Note. Ostensibly, binning can be set via INDI options as NxM where N and M may take any value you wish. This feature does not work. Binning can really be set only via "brain" button.]
- 17. IF YOU WILL NOT BE AUTOGUIDING: Disable mount guide output:
 - Select the Guiding tab,
 - in the group Shared parameters disable mount guide output (uncheck the box); Guide output DISABLED should appear in the lower left of the main window. This should prevent PHD2 accidentally interfering, e.g., with the PEPSI guider.
- 18. Set up automatic frame capture:
 - Select the Global tab,
 - check Enable diagnostic image logging, then
 - in the group Save Guider Images check Until this count is reached,
 - set the value (100 is the maximum).
 - the files are stored on the vattcontrol server
 - The Dark Library is located in the directory /home/vattobs/.phd2/.
 - The directory /home/vattobs/PHD2/PHD2 CameraFrames... is automatically created for the session.
 - If you need to capture more than 100 images, make a renamed copy of the session directory; new fits files should start populating the original sesson directory.
- Start Imaging
 - 1. in the bottom left of the PHD2 window there is a button with 2 arrows forming a circle. Click that button.
 - 2. the button should gray out, the stop sign button should turn red, and images should start appearing

Offset Guider Stage

Note: All numbers are GUI units. The travel limits are accurate but the diagram is only an approximation.



From:

https://lavinia.as.arizona.edu/~tscopewiki/ - MOON

Permanent link:

 $https://lavinia.as. arizona. edu/\sim tscopewiki/doku.php?id=phd2:phd2_guiding_abbreviated\&rev=1538780552$

Last update: **2018/10/05 16:02**

