

# Schulman Telescope Startup Procedure

Updated 8/4/2022 - Travis Deyoe

The order of operations below is designed for time efficiency. Missing a step could lead to frustration as some steps may feel “out of order” but are designed to reduce down time waiting for things to power on.

## Pre-Startup Checks

### Pull Off Tarps

The Telescope, Controller, and desk will always be tarped whenever the telescope is put into Lightning Shutdown. They will need to be removed before inspecting or moving the telescope.

Perform your best interpretive dance to appease the tarp gods. If that does not make the tarp fall off you must remove it manually. Folding it up and placing it to the right of the brown cabinet is a nice touch.

### Check Telescope Position

Verify the telescope is not at any limits. If it is or looks “wrong” to you, move it manually into a safe position before the next steps. This guarantees that it will be able to successfully and safely home in a future step. It's recommended to place it either at [Zenith](#) or the [Park](#) position.

### Check Emergency Stops

If engaged, release any E-stops on the Hand Paddle, Telescope Controller, and the MaxDome Controller by pulling them outward. They all appear as big red buttons that scream “PRESS ME IN CASE OF EMERGENCY”.



## Check the Telescope Balance State

The telescope is in a balanced state when one of the following conditions are met:

- The camera is on with a single weight attached at the “top” of the backplate.
- The focuser is on with both eyepiece weights attached on either side of the focuser and there is no weight on the “top” of the telescope.

In either state an eyepiece should be in the 6” refractor and the mirror covers are open (this will be done later in [this step](#)). If the telescope is in neither of these states, then place it in one of the [Configurations](#) now or at the very least before [homing the telescope](#).

## Check RA Encoder Tape

Follow the RA [optical tape](#) along the big RA wheel and check for any smudges, bug guts, and so forth. The WEST [read head](#) is active while the east read head is not currently utilized, so make sure through the entire motion of the telescope (in RA of course) that there is nothing blocking the reading of the tape on the west side and that there is nothing obstructing the read head's ability to “see” the optical tape.

Make certain both the [drive and idler bearings](#) are also free of anything that might be transferred to the optical tape. A bit of felt is held in place there that *should* wipe off anything, but its best to check still.


If anything is observed, use a microfiber cloth or TEX wipe to wipe it away. You can use 99% isopropyl alcohol if necessary. Note that you should only wipe along the narrow width NOT along the circumference (or length) of the tape.


# Powering Everything On

Now that you have inspected the telescope for safety, it is now time to start turning things on.

## Power On UPS's

First plug in the big and small UPS's to the left of the desk. The big UPS should be twisted clockwise after insertion in order to secure it in the socket. The big UPS powers the larger controller box on the wall above it, while the small UPS powers basically everything else.





Next you must turn on both UPS's. Press and hold the corresponding “on” button for at least a second until you hear a beep, then let go. For the big UPS this will take a few moments as it cycles through some lights (shown in full in the GIF below). The small UPS will power on quicker.





Both UPS's will immediately supply power to their output plugs, so no further button pressing is

necessary.

## Power On Controller and Desktop Computer

The big gray box on the wall is the Controller. Turn it on by turning the large red switch on the bottom left of the Controller box to the right (clockwise). Assuming the UPS was powered on in the last step, fans and other noises will be heard as the system comes on.



Now is also when you should turn on the desktop computer. It is under the desk behind the little door on the left. The power button is the same color as the computer case so in a dimly lit room (like it most likely is now without the dome open) you may need a light to find it.

## Power on TIM Unit

The TIM unit is a small gray/black box on back of the telescope just below where the camera or eyepiece is installed. There is a standard power switch on the left side to turn it on.

## Check Controller Ethernet Cable

While the Controller and desktop computer are powering on (the Controller takes about 15 years to do so), go into the warm room. Now go into the closet. There is a gray ethernet cable labelled "Controller." Plug this into the switch on the right wall and confirm there are happy internet lights on the switch.



## Desktop Tasks

Proceed back to the desktop computer, which should be fully powered on. Log in to the computer (standard SkyCenter password). The next few tasks will all be done on this computer.

### Open Mirror Covers

Open the [RCOS TIM software](#) from the desktop link or toolbar quick link.





Connect to the TIM unit (by clicking the connect button) and navigate to the “Primary Mirror Cover” tab.



Open the mirror covers by clicking the “Open” button.






If the mirror covers aren't opening correctly or the current stays high (over 1000 milliamps) then there is a problem. Abort the opening (or closing). You attempt to open them again but if the problem persists additional help is needed (AKA call Travis or ask Mountain Ops if they are still around).

## Remotely connect to MIC and PubSub

Launch [VNC Viewer](#). It will appear on the middle right of the desktop (or just search for it in the start menu). You will now want to remotely connect to the MIC and PubSub computers that run the Controller. This is what VNC Viewer does, so just double-click on the MIC and PUBSUB links in VNC Viewer and it will open a window for each.



## Verify MIC and PubSub Time

**NOTE: At this time PubSub is dumb and will display a “Logout” screen. Click that button and it will display an empty desktop. To find the files/shortcuts for later steps that are on the desktop, you will need to use the file manager in the Programs menu (top left of the screen)**


Make it so you can view the top right of both screens next to each other and confirm that the two computer times are within about 5 seconds of each other. If they are not you must perform the following task: [Sync Controller Times](#).

## Start PubSub Software

Initially the desktop will be blank (black). Start the PubSub processes by pressing the tool utility icon at the top of the PubSub desktop. It is circled in the image below:



This will clear the database and give everything a clean start. Eventually (a few minutes) the “JADE” agent will load and the desktop will look like the below:



The small icons to the left of each folder icon can be pressed to expand them and reveal the list as shown. Once the “Instruments-xx01\_0m8a\_doma” process is loaded under its section, PubSub is ready to communicate with the telescope (and the user). The “RPC\_Gateway” process will not show up until communication to PubSub commences through the web browser. This is in the next step. It is OK to close the VNC window.


From PubSub's desktop folder double-click on the “Clear and Restart PubSub” program. This will open both a terminal window and a GUI. The GUI will slowly populate with a list of items. **Do not proceed until all those below show up**

- Main-Container
- Observatory\_doma\_tus
- Site\_tus
- jTCS\_0m8a\_doma\_tus
- Instruments-xx01\_0m8a\_doma
- (RPC\_Gateway) ← only shows once connected (via [this step](#)) to the controller, will not show initially

## Access the LCOGT (PubSub) GUI

Now that the system is up and running with drives, servos, and PubSub, access the LCOGT GUI by following the steps below.

Open [Google Chrome](#) and click the bookmark labeled PubSub. You will be presented with the screen below:



The Username is unused so leave it as is or write something funny for the next operator to see. However, *default* **is** required for the “config file” field. Once these items are entered or confirmed to already exist, click OK.

PubSub will now take a long time to load. Go read a book (I recommend [Remembrance of Things Past](#)) and come back when you are done. If it feels like it's taking too long (a couple minutes) try refreshing and logging in again.



The screenshot shows the TUS web interface with the 'State' tab selected. The interface is divided into several sections: 'Tracking' with control buttons, 'Other States' with a table of system states, 'State' with a table of component states, 'Instrument State' with a table of instrument details, 'Description' with a table of description details, 'Current Message Queue Size' with a table of queue sizes, 'Behaviours' with a table of behaviour counts, and 'Software Repository Path' with a table of software paths. The top right corner shows the date and time: 2016-11-01 23:21:41 UTC, 18:45:10 LST. The top left corner shows the URL: pubsub.tus:8080/gwtpubsub2/#tus/doma/0m8a/.

Take note of the colors. You should mostly see grays (items that just aren't used in our setup) or greens. There may be a yellow or two, but if there is any red there may be an issue. If see red and suspect an issue call Travis.

## Homing the Telescope

The telescope must be homed before it can be operated.

When PubSub loads it should already be on the Axes tab. If not, click on it.



State	Observation Script	Sequencer	Source	Tracking	Axes	Guide	Instrument
<b>Agent State</b> Mount <span style="background-color: green; color: black;">Okay</span>							
<b>Axes Command</b>							
Agent Enable				Agent Disable			
Roll		Pitch		Rotator			
Standby		Standby		Off			
Homing		Homing		UNKNOWN			
<input checked="" type="radio"/> Pos <input type="radio"/> Vel 0.0 deg		<input checked="" type="radio"/> Pos <input type="radio"/> Vel 0.0 deg		<input checked="" type="radio"/> Pos <input type="radio"/> Vel 0.0 deg			
Slew		Slew		Slew			
Halt		Halt		Halt			
Home		Home		Home			
Park		Park		Park			
Unwrap		Unwrap		Unwrap			
Stop		Stop		Stop			
Stop Reset		Stop Reset		Stop Reset			
Enable		Enable		Enable			
Disable		Disable		Disable			
Goto Pos L1		Goto Pos L1		Goto Pos L1			
Goto Neg L1		Goto Neg L1		Goto Neg L1			
Recover L2		Recover L2		Recover L2			
Fault Reset		Fault Reset		Fault Reset			
Slew		Slew		Slew			
Halt		Halt		Halt			
Park		Park		Park			
Home		Home		Home			
Stop		Stop		Stop			

Once homed successfully the state field will briefly go to "stopped" and then finally "Halted" - "L1 Positive Limit" in both axes:

State
Observation Script
Sequencer
Source
Tracking
**Axes**
Guide
Instrument

**Agent State**

Mount
Okay

**Axes Command**

Agent Enable
Agent Disable

Roll	Pitch	Rotator
Okay	Okay	Off
Halted L1 Positive Limit	Halted L1 Positive Limit	UNKNOWN
<input checked="" type="radio"/> Pos <input type="radio"/> Vel	<input checked="" type="radio"/> Pos <input type="radio"/> Vel	<input checked="" type="radio"/> Pos <input type="radio"/> Vel
0.0 deg	0.0 deg	0.0 deg
Slew	Slew	Slew
Halt	Halt	Halt
Home	Home	Home
Park	Park	Park
Unwrap	Unwrap	Unwrap
Stop	Stop	Stop
Stop Reset	Stop Reset	Stop Reset
Enable	Enable	Enable
Disable	Disable	Disable
Goto Pos L1	Goto Pos L1	Goto Pos L1
Goto Neg L1	Goto Neg L1	Goto Neg L1
Recover L2	Recover L2	Recover L2
Fault Reset	Fault Reset	Fault Reset

Slew
Halt
Park
Home
Stop

**Park Wizard**

Now go to the *Source* tab and move the telescope out of the limits to a valid sky position. If the telescope is not going to be used immediately, typically the telescope is sent to the **Park** position. Remember to stop the tracking loop (via the big button or the right that says "Stop Tracking Loop", if observing is not going to start. The **Zenith** position is inputted in the picture below.



pubsub.tus:8080/gwtpubsub2/#tus/doma/0m8a/Source

TUS **Alive** 2016-11-01 23:25:14 UTC 18:48:46 LST

Tools Chat (Alan)

State Observation Script Sequencer **Source** Tracking Axes Guide Instrument Ins View Spectrograph Calibrate Focus Optical Tube Telescope Services 1 Telescope Services 2

**Agent State**  
Astrometric **Okay**

**Point**  
Point/Next Start End  
Skip Store Clear  
Goto nearest pointing star ☒ Clear local offsets

**Source**

Name	
Right Ascension Source	NaN h
Declination Source	NaN deg
Coordinate System	
Equinox Source	NaN yr
Limit Expected	Horizon Limit
Limit Time Left	3.65 h
Moon Zenith Distance	61.89 deg
Sun Zenith Distance	77.69 deg

**Telescope**

Tracking In Tolerance	<b>Out Of Tolerance</b>
Air Mass	2.3429
Altitude	25.15 deg
Azimuth	179.23 deg
Hour Angle	-00:03:18.493 h
Zenith Distance	64.8 deg
Sun Separation	132.20 deg
Moon Separation	47.44 deg

**Space Motion**

Source Space Motion Enabled	false
Source Parallax	NaN arcsec
Source Proper Motion Epoch	NaN yr
Source Proper Motion Right Asc	NaN arcsec/yr

**Source Selection**  
Astrometric Kernel State: **Stopped**

Known objects:  Go

Source Name: none Fetch Clear

Coordinates  
Coordinate System: APPARENT\_HA  
Hour Angle: 0 h  
Declination: 32 deg

Space Motion  
Orbital Elements  
Where is it?  
When?  
Where will it be?  
☒ Clear local offsets  
Go Moon Flat  
Stop Unwrap Roll Unwrap Rot

**Time**

Local Apparent Sidereal Time	18:48:46.944 h
Modified Julian Day	57693.9759 MJD
Julian Epoch	2016.8363 yr
TAI Minus UTC	36 s
TT Minus TAI	32.1840 s
UT1 Minus UTC	-0.3238 s

**Orbital Element**

Source Orbital Element Scheme	
Source Orbital Element Argument	NaN deg
Source Orbital Element Daily Mo	NaN deg
Source Orbital Element Eccentric	NaN
Source Orbital Element Epoch O	NaN MJD
Source Orbital Element Epoch Q	NaN MJD
Source Orbital Element Longitud	NaN deg

**Refraction**  
Pressure: mbar  
Humidity: %  
Temperature: °C  
Apply Override  
Clear Override

**Tracking**  
Disable Roll Disable Pitch Enable Rotator  
Stop Tracking Loop  
Rotator Mode  
SKY Set

**Refraction**  
Manual Override False  
Air Temperature Value 0 °C  
Barometric Pressure Value 0 mbar  
Humidity Value 0 %  
Wavelength 0.6000 um  
Guiding Wavelength NaN um

**Pointing Control**  
M1 and M2 Alignment False Enable  
Collimation False Enable  
Roller Encoders False Enable  
Encoder Non-Linearity False Enable

**Pointing Corrections**  
Polar Motion X 0.1892 arcsec  
Polar Motion Y 0.2811 arcsec  
Collimation Correction Enabled **False**  
Collimation Correction Pitch 0 arcsec  
Collimation Correction Roll 0 arcsec

Alan Send

Datum Tree File Operations Log Messages

Please see the [Using the LCOGT GUI](#) section for more information.

# Normal Startup Operations

You have now successfully pulled the Schulman telescope out of Lightning Shutdown! Congrats. It is now time to start your normal program procedures to get everything ready for a SkyNights program or remote operation.

From:  
<https://lavinia.as.arizona.edu/~tscopewiki/> - **MOON**

Permanent link:  
[https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:lemmon:schulman\\_32:startup\\_procedure&rev=1663193333](https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=public:catalinas:lemmon:schulman_32:startup_procedure&rev=1663193333)

Last update: 2022/09/14 15:08

