

# TCSng Commands

This is the most comprehensive list to date of the TCSng requests and commands.

## Requests

ALL Bulk information

Args: N/A

Returns: [MOT] [RA] [DEC] [HA] [UT] [ALT] [AZ] [SECZ] [Epoch]

MOT = (see MOTION)

RA(Right Assention) = HH:MM:SS.ss

DEC(Declination) = +DD:MM:SS.ss

HA(Hour Angle) = HH:MM:SS

UT(Universal Time) = HH:MM:SS

ALT(Elevation) = XXX.xx

AZ(Azmouth) = XXX.xx

SECZ(airmass) = XX.xx

EPOCH = EEEE.e

AZ Azmouh

Args: N/A

Returns: [ddd.dd]

BEAM Chop/Nod info for chopping secondary

Args: N/A

Returns: ???

CORRECTIONS String describing what corrections and rates are enabled/disabled

Args: N/A

Returns: MPNARFp+tob

M=Proper Motion

P=Precession

N=Nutation

A=Aberration

R=Refraction

F=Flexure

p=Parallax

+ =pointing model used... can change to a,b,c,d?

t=Sidereal

o=Object

b=Bias

If disabled, character will be replaced by "\_"

DATE date based on UT

Args: N/A

Returns: [MM/DD/YYYY]

DEC Declination

Args: N/A  
Returns [ddmmss.ss]

DISABLE Output state  
Args: N/A  
Returns: 1 for disabled, 0 for enabled

DISEPOCH Current Epoch  
Args: N/A  
Returns: XXXX.x

EL Elevation  
Args: N/A  
Returns: [ddd.dd]

EQ Equinox  
Args: N/A  
Returns: XXXXX.x

HA Hour Angle  
Args: N/A  
Returns: [dd:mm:ss]

JD Julian Date  
Args: N/A  
Returns: [JJJJJJJ.j]

LIMIT limit status bits (ACCORDING TO JAVA GUI)  
Args: N/A  
Returns: this returns an 8 bit integer whose bits represent the following

- bit0(LSB) = RA low limit
- bit1 = RA upper limit
- bit2 = DEC low limit
- bit3 = DEC upper limit
- bit4-6 = unknown ????????
- bit7 = limit warning?
- bit8 = limit warning?

a 1 indicates limit active, 0 indicates limit not active

LIMIT limit status bits (ACCORDING TO ERIC CHRISTIENSEN)  
Args: N/A  
Returns: this returns an 8 bit integer whose bits represent the following

- bit0(LSB) = RA/HA limit
- bit1 = DEC limit
- bit2 = derot.
- bit3 = hor. hard limit
- bit4 = hor. soft limit

```
bit5 = focus lo limit?  
bit6 = focus hi limit?  
a 1 indicates limit active, 0 indicates limit not active
```

MOTION Motion status bits

Args: N/A

Returns: this returns an 8 bit integer whose bits represent the following

```
bit0(LSB) = RA/AZ  
bit1 = DEC/EL  
bit2 = FOC  
bit3 = DOME  
bit4-8 = undefined  
a 1 indicates axis in motion, 0 indicates no motion
```

PAD String describing hardware paddle button states

Args: N/A

Returns: any combination of the following characters

```
N = North  
S = South  
E = East  
W = West  
D = Drift (if not present, assume Guide)
```

A character is present if switch active, otherwise switch inactive

PADDRIFT Hardware paddle drift rate arcsec/sec

Args: N/A

Returns: -XXXXXXXXX.xxx

PADGUIDE Hardware paddle guide rate arcsec/sec

Args: N/A

Returns: -XXXXXXXXX.xxx

RA Right Assention

Args: N/A

Returns: [ddmmss.ss]

SECZ Air Mass

Args: N/A

Returns: [XXXXX.XX]

ST Sidereal Time

Args: N/A

Returns: [hh:mm:ss]

TIME Universal Time

Args: N/A

Returns: [HH:MM:SS]

VERIFY Verify that an RA/DEC position is within telescope limits

```
Args: [RA] [DEC] [Epoch]
      RA=HH:MM:SS.ss
      DEC=DD:MM:SS.ss
      Epoch=EEEE.eeee
Returns: 1 if coordinate is within limits
```

```
XALL "Extended ALL"
Args: N/A
Returns: [FOC] [DOME] [IIS] [PA] [UTD] [JD]
         FOC(focus pos) = +XXXXXX
         DOME(Dome Position) = -180 (always this value...)
         IIS(???) = -224.4 (always this value...)
         PA(Paralactic Angle) = -145.7 (always this value...)
         UTD(UT Date) = MM/DD/YYYY
         JD(Julian Date) = XXXXXXXX.x
```

```
XDEC "Extended DEC"
Args: N/A
Returns: [COM] [NEXT] [REF] [OFF] [WOB] [DIFF] [BIAS] [GUIDE] [DRIFT]
         COM(Commanded Position) = +HH:MM:SS.ss
         NEXT(Next Position) = +HH:MM:SS.ss
         REF(Reference Position) = +HH:MM:SS.ss
         OFF(Offset Position) = +HH:MM:SS.ss
         WOB(Wobble) = +HH:MM:SS.ss
         DIFF(Difference) = +XXXXXXXXXX.xxx
         BIAS(Bias Rate) = +XXXXXXXXXX.xxx
         GUIDE(Guide Rate) = +XXXXXXXXXX.xxx
         DRIFT(Drift Rate) = +XXXXXXXXXX.xxx
```

```
XRA "Extended RA"
Args: N/A
Returns: [COM] [NEXT] [REF] [OFF] [WOB] [DIFF] [BIAS] [GUIDE] [DRIFT]
         COM(Commanded Position) = HH:MM:SS.ss
         NEXT(Next Position) = HH:MM:SS.ss
         REF(Reference Position) = HH:MM:SS.ss
         OFF(Offset Position) = +HH:MM:SS.ss
         WOB(Wobble) = +HH:MM:SS.ss
         DIFF(Difference) = +XXXXXXXXXX.xxx
         BIAS(Bias Rate) = +XXXXXXXXXX.xxx
         GUIDE(Guide Rate) = +XXXXXXXXXX.xxx
         DRIFT(Drift Rate) = +XXXXXXXXXX.xxx
```

## Commands

```
ABERRATE Aberration corrections enable/disable
Args: "ON" = enable, any other string will disable
Returns: "OK" or "FAILED"
```

BIAS Bias enable/disable  
Args: "ON" = enable, any other string will disable  
Returns: "OK" or "FAILED"

BIASDEC DEC bias rate in arcseconds/second  
Args: [XXXXX.XX]  
Returns: "OK" or "FAILED"

BIASRA RA biasrate in arcsseconds/second  
Args: [XXXXX.XX]  
Returns: "OK" or "FAILED"

CANCEL Cancel current move  
Args: N/A  
Returns: "OK" or "FAILED"

CLEARDIFF Clear RA and DEC difference value  
Args: N/A  
Returns: N/A

DISABLE disable motion output  
Args: N/A  
Returns: "OK" or "FAILED"

DISEPOCH Set Epoch  
Args: XXXX.x  
Returns: "OK" or "FAILED"

DECLARE Initialize current position  
Args: "INITNEXT" to initialize "NEXT" position as current position  
"INITCOM" to initialize "COMMANDED" position as current position  
Returns: "OK" or "FAILED"

ELAZ Move to position in Elevation and Azmouth  
Args: [EEE.EE] [AAA.AA]  
Returns: "OK" or "FAILED"

ENABLE enable motion output  
Args: N/A  
Returns: "OK" or "FAILED"

FLEX Flexure corrections enable/disable  
Args: "ON" = enable, any other string will disable  
Returns: "OK" or "FAILED"

LIMIT Limit override >> USE WITH EXTREME CAUTION!!!!  
Args: "INHIBIT" will override limits, all other strings will enable limits  
Returns: "OK" or "FAILED"

**MOVNEXT** Move to NEXT position

Args: N/A

Returns: "OK" or "FAILED"

**MOVOFF** move to OFFSET position

Args: N/A

Returns: "OK" or "FAILED"

**MOVRADC** Move to RA-DEC position

Args: RA DEC EPOCH RAPM DECPM

RA = HH:MM:SS.ss

DEC = +DD:MM:SS.ss

EPOCH = EEEE.eeee

RAPM(RA Proper Motion) = XXXXX.xxx

DECPM(DEC Proper Motion) = XXXXX.xxx

Returns: "OK" or "FAILED"

**MOVSTOW** Move to stow position

Args: N/A

Returns: "OK" or "FAILED"

**MOVWOB** MOVWOB beam

Args: ???

Returns: ???

**NEXTPOS** Set NEXT position

Args: RA DEC EPOCH RAPM DECPM

RA = HH:MM:SS.ss

DEC = +DD:MM:SS.ss

EPOCH = EEEE.eeee

RAPM(RA Proper Motion) = XXXXX.xxx

DECPM(DEC Proper Motion) = XXXXX.xxx

Returns: "OK" or "FAILED"

**NUTAT** Nutation corrections enable/disable

Args: "ON" = enable, any other string will disable

Returns: "OK" or "FAILED"

**PAD** Software paddle command [Direction] [rate] or PAD XX for termination

Args: [Direction] [rate]

DIRECTION = NORTH, SOUTH, EAST, WEST, NE, NW, SE, SW

RATE = XXXXXX.xx (arcsecs/sec)

any string not described in DIRECTION will terminate paddle

Returns: "OK" or "FAILED"

**PADDLE** Paddle enable/disable

Args: "ON" = enable, any other string will disable

Returns: "OK" or "FAILED"

PADDRIFT Paddle Drift rate in arcseconds/second

Args: [XXXXX.XX]

Returns: "OK" or "FAILED"

PADGUIDE Paddle Guide rate in arcseconds/second

Args: [XXXXX.XX]

Returns: "OK" or "FAILED"

PARALLAX Parallax corrections enable/disable

Args: "ON" = enable, any other string will disable

Returns: "OK" or "FAILED"

PARAM ???

Args: ???

Returns: ???

PRECES Precession corrections enable/disable

Args: "ON" = enable, any other string will disable

Returns: "OK" or "FAILED"

PROPMO Proper motion corrections enable/disable

Args: "ON" = enable, any other string will disable

Returns: "OK" or "FAILED"

REFPOS REFerence POSition (tod)

Args: ???

Returns: ???

REFRAC Refraction corrections enable/disable

Args: "ON" = enable, any other string will disable

Returns: "OK" or "FAILED"

STEPDEC Move Declination XXXXX.XX arcseconds

Args: [XXXXX.XX]

Returns: "OK" or "FAILED"

STEPRA Move Right Assention XXXXX.XX arcseconds

Args: [XXXXX.XX]

Returns: "OK" or "FAILED"

TRACK Enable/Disable sidereal tracking

Args: "ON" = enable, any other string will disable

Returns: "OK" or "FAILED"

WOBBLE WOBBLE -HH:MM:SS.ss -DD:MM:SS.ss

Args: ???

Returns: ???

Catalogs Command

ABELL ABELL Catalog object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

FK5 FK5 Catalog object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

IC IC Catalog object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

NGC NGC Catalog object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

OKESTONE Okestone Catalog object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

PPM PPM Catalog object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

SAO SAO Catalog Object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

YBCS YBCS Catalog Object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

ZWICKY ZWICKY Catalog object XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

Planets Command:

MERCURY Track Mercury  
Args: N/A  
Returns: "OK" or "FAILED"

VENUS Track Venus  
Args: N/A  
Returns: "OK" or "FAILED"

MARS Track Mars  
Args: N/A



Returns: "OK" or "FAILED"

JUPITER Track Jupiter

Args: N/A

Returns: "OK" or "FAILED"

SATURN Track Saturn

Args: N/A

Returns: "OK" or "FAILED"

URANUS Track Uranus

Args: N/A

Returns: "OK" or "FAILED"

NEPTUNE Track Neptune

Args: N/A

Returns: "OK" or "FAILED"

PLUTO Track Pluto

Args: N/A

Returns: "OK" or "FAILED"

MOON Track Moon

Args: N/A

Returns: "OK" or "FAILED"

SUN Track Sun

Args: N/A

Returns: "OK" or "FAILED"

Dome Request:

DOME Dome control information

Args: "PARAM" returns dome setup parameters, all other strings return control info

Returns:

Parameters: [CPD] [SD] [W] [SDW] [NU] [RHO] [PHI] [LOOK] [HOLD]

CPD(Counts Per Degree) = XXX.xxxxxxx

SD(Stow Degrees)= XXX.xxxxxxx

W(Dome Width) = XXX.xxxxxxx

SDW(Stow Dome Width)= XXX.xxxxxxx

NU = XXX.xxxxxxx

RHO = XXX.xxxxxxx

PHI = XXX.xxxxxxx

LOOK(Lookahead) = XX

HOLD(Hold Dome) = XX

Control Info: [DEL] [MOD] [INIT] [TELAZ] [AZ] [HOME]

DEL(Delta Position) = +XXX.XXXXXXX

MOD(Mode) = XX

INIT(Initialized) = XX

```
TELAZ(Telescope Azmouth) = +XXX.XXXXXXX  
AZ(Dome Azmouth) = +XXX.XXXXXXX  
HOME(Home Position) = +XXX.XXXXXXX
```

#### Command:

```
DOME    Command dome control  
  Args: This command takes one argument at a time from the following  
  AUTO   Autodome enable  
        Args: ON = autodome on, any other = autodome off  
  Returns: "OK" or "FAILED"
```

```
INIT    Initialize dome  
  Args: N/A  
  Returns: "OK" or "FAILED"
```

```
STOW    Stow dome  
  Args: N/A  
  Returns: "OK" or "FAILED"
```

```
LOOKAHEAD Lookahead enable  
  Args: positive nonzero number=enable, any other = disable  
  Returns: "OK" or "FAILED"
```

```
PARAM    Set Dome Parameters  
  Args: [CPD] [SD] [W] [SDW] [NU] [RHO] [PHI] [LOOK] [HOLD]  
  CPD(Counts Per Degree) = XXX.xxxxxxx  
  SD(Stow Degrees)= XXX.xxxxxxx  
  W(Dome Width) = XXX.xxxxxxx  
  SDW(Stow Dome Width)= XXX.xxxxxxx  
  NU = XXX.xxxxxxx  
  RHO = XXX.xxxxxxx  
  PHI = XXX.xxxxxxx  
  LOOK(Lookahead) = XX  
  HOLD(Hold Dome) = XX  
  Returns: "OK" or "FAILED"
```

```
PADDLE   Control Paddle buttons  
  Args: RIGHT = move right, LEFT = move left, any other= stop  
  Returns: "OK" or "FAILED"
```

#### Focus Request

```
FOCSPEED Focus Speed  
  Args: N/A  
  Returns: ["FAST" or "SLOW"]
```

```
FOCUS    Focus position  
  Args: N/A
```

Returns: +XXXXX

## Command

FOCUS move to absolute focus value XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

RELFOCUS relative move focus value XXXXXXXX  
Args: XXXXXXXX  
Returns: "OK" or "FAILED"

FOCZERO Zero current focus position  
Args: N/A  
Returns: "OK" or "FAILED"

FOCSTOP focus paddle stop  
Args: N/A  
Returns: "OK" or "FAILED"

FOCUP focus paddle up  
Args: N/A  
Returns: "OK" or "FAILED"

FOCDN focus paddle down  
Args: N/A  
Returns: "OK" or "FAILED"

FOCSPEED Set focus speed  
Args: "FAST" sets to fast, all other strings set speed slow  
Returns: "OK" or "FAILED"

## PEC Request

PECSTAT Current PEC operation status  
Args: N/A  
Returns: [PEC\_Condition] [PEC\_Count] [PEC\_Index] [PEC\_Mode]

PECPRG Current PEC programming status  
Args: N/A  
Returns: [Percent\_Done] [PEC\_Correction]

## Command

PECFILE Attempt to create a PEC file.  
Args: ???  
Returns: ???

PEC Turn on PEC  
Args: "ON" = enable, any other string will disable

Returns: "OK" or "FAILED"

## Servo Request

CON ??? >> SERVO STUFF... NOT FOR NORMAL USE  
Args: ???  
Returns: ???

SAMDATA ??? >> SERVO STUFF... NOT FOR NORMAL USE  
Args: ???  
Returns: ???

SAMDONE ??? >> SERVO STUFF... NOT FOR NORMAL USE  
Args: ???  
Returns: ???

SERVO ??? >> SERVO STUFF... NOT FOR NORMAL USE  
Args: ???  
Returns: ???

## Command

WCON axis, gd gp gi dmax vmax groot >> SERVO CONST... DO NOT MODIFY  
Args: ???  
Returns: ???

SERVO ??? >> AXIS SERVO SAMPLING... DO NOT MODIFY  
Args: ???  
Returns: ???

GD axis, value >> SERVO CONST... DO NOT MODIFY  
Args: ???  
Returns: ???

GP axis, value >> SERVO CONST... DO NOT MODIFY  
Args: ???  
Returns: ???

GPI axis, value >> SERVO CONST... DO NOT MODIFY  
Args: ???  
Returns: ???

DMAX axis, value >> SERVO CONST... DO NOT MODIFY  
Args: ???  
Returns: ???

VMAX axis, value >> SERVO CONST... DO NOT MODIFY  
Args: ???

Returns: ???

PERMAX axis, value >> SERVO CONST... DO NOT MODIFY

Args: ???

Returns: ???

SAMPLE axis, interval, total samples >> AXIS SERVO SAMPLING... DO NOT MODIFY

Args: ???

Returns: ???

DUMPSAM axis >> AXIS SERVO SAMPLING... DO NOT MODIFY

Args: ???

Returns: ???

SAMSTART ??? >> AXIS SERVO SAMPLING... DO NOT MODIFY

Args: ???

Returns: ???

SAMABORT ??? >> AXIS SERVO SAMPLING... DO NOT MODIFY

Args: ???

Returns: ???

undefined??? Request

TEST1 ??? >> probably useless but is currently in the command set

Args: ???

Returns: ???

INDEX ???

Args: ???

Returns: ???

PP ???

Args: ???

Returns: ???

SRVFRQ ???

Args: ???

Returns: ???

Command

SYSSAVE ???

Args: ???

Returns: ???

YSKILL ???

Args: ???

Returns: ???

From: <https://lavinia.as.arizona.edu/~tscopewiki/> - **MOON**

Permanent link: [https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=tcs:tcsng\\_command\\_list&rev=1352907579](https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=tcs:tcsng_command_list&rev=1352907579)

Last update: **2012/11/14 08:39**

