

- make sure the ground wire is connected:
 - first to the mirror cell and
 - then to the camera
- insert the nozzle into the dewar, and attach it using the bungee cord
- opening the valve, start filling the camera's dewar with LN2; if using remotely controllable valve follow [instructions in a separate document](#)
- fill out LN2/camera log – listen for full dewar
- cease flow when dewar is full
- disconnect LN2 filler hose from camera dewar, move storage dewar off of telescope platform and south, to dome silo wall)
- remove camera ground wire and clip it on silo, near storage dewar

From:

<https://lavinia.as.arizona.edu/~tscopewiki/> - **MOON**

Permanent link:

https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=vatt:liquid_nitrogen_for_itl_cameras

Last update: **2024/06/11 14:38**

