

	Lightning Shutdown & Startup / Jul 7, 2021 / M Franz, P Gabor, D Brown (with thanks to Ralf Jansen, Taras Golota et al.)	✓ X
General rule 0	😊 Call Gary Gray, Chris Johnson or other members of the A-team ahead of time if it is not clear how to proceed!	
General rule 1	😊 Always make sure you will know how to reconnect any cables you disconnect!	
Case A	Observatory in “warm” shutdown. Assumes telescope is stowed 🤔, TCS glue, and all other software needed to run the telescope is stopped 🤔, amplifiers OFF 🤔, Neslab OFF 🤔, and hydrostatic bearing OFF 🤔. GO IMMEDIATELY TO STEP 1.	
Case B	The telescope is on the sky, and a big boom arrives outta' nowhere → STEP 0.	
STEP 0	Just follow this checklist. Do not worry about the warm shutdown checklist .	
Control room	TCSglue: Stow the telescope	
Control room	TCSglue: Disable drives	
Control room	TCSglue: Close mirror cover	
Control room	TCSglue: Close dome slit	
STEP 1	The following action items take place on the building's Level 2	
Control room	Out of the three new X-terms, pick the one where you can reach its own “surfer” desktop most readily (typically by closing various remote sessions). On the X-term's own desktop, open a terminal. In the terminal type either <code>haltvatt</code> or <code>./haltvatt</code> and hit ENTER. The shutdown script will run, and it will power down every computer, including all four xterms (the three new ones and the older one). The , with the exception of <code>vatttel</code> (It is no longer necessary to use the power button on <code>vattdata</code> to shut it down fully). <i>Note. The <code>haltvatt</code> script is not resident, and so cannot be used, on <code>vattxt3</code> (the older xterm with the smaller monitor).</i>	
TCS room	Turn <code>VATTtel</code> off (big black toggle button)	
TCS room	Power down the M2 PI controller	
TCS room	Check 🤔 that the amplifiers are off	
TCS room	Turn off the GPS unit (flip the small on/off switch). No need to power down the NTP server (small box on top of the GPS unit).	
Server (Instrument) room	Open the computer rack. Check that the servers are off by inspecting their power indicators (they ought to be amber).	
Server (Instrument) room	Press and hold the power button on each of the HP UPSs (bottom of rack, under the <code>vattdata</code> server), until you hear the power go off (~5 sec).	
Server (Instrument) room	Close the computer rack. (The doors are electrically bonded to the frames, and a closed rack provides more protection for people and for the computers.)	
STEP 2	The following action items take place on the building's Level 1	
Lvl 1, loading dock	Turn off the UPS unit in the loading dock; turn the key to the OFF position	
Lvl 1, Telecom room	When the UPS is really off, go to panel A, and switch off the three bound-together 100 A circuit breakers marked Panel C in red.	
Lvl 1, loading dock	Unplug the UPS unit from the wall socket	
Lvl 1, loading dock	Unplug building supply lines from the back of the UPS unit	
Lvl 1, loading dock	Hang the plugs up on hooks on the wall next to the UPS, using the lanyards provided on each plug.	

	Lightning Shutdown & Startup / Jul 7, 2021 / M Franz, P Gabor, D Brown (with thanks to Ralf Jansen, Taras Golota et al.)	✓ x
Lvl 1, loading dock	<i>For long shutdowns, disconnect the DC supplies with the DC breakers internal to the UPS units (Do not attempt unless instructed.)</i>	
STEP 3	The following action items take place back on the building's Level 2	
TCS room	Unplug AC power from west wall raceway quad: there are four sockets marked in red Left Raceway Quad / UPS power, and four sockets marked in white Right Raceway Quad / Non-UPS'd Conditioned. Disconnect all five power cords plugged into these sockets.	
TCS room	Disconnect the GPS antenna from the back of the black GPS receiver	
Server (Instrument) room	At the rear of the rack, unplug the two twistlock plugs feeding the rack power chords where they are plugged into the 220V wall outlets. They have red labels mentioning circuit breakers 7 and 9, and 11 and 13, resp.	
STEP 4	The following action items take place in various locations	
Case A	Telescope already in warm shutdown	
Dome	Double check that the dome short is in	
Dome	Close dome vents	
	Done	
Case B	Telescope was on the sky	
Dome	FIRST! UNPLUG SLIT POWER and INSERT DOME SHORT	
Dome	Insert the stow pins	
Dome	Shut off everything on the telescope necessary to enter warm shutdown	
	Finder 'scopes: power down the older one and close covers on both	
	Guider camera: power down (inline switch)	
	Close dome vents	
Basement	Stop the hydrostatic bearing	
Silo, lvl 2	Turn Neslab OFF	
	Done	
STARTUP	Reverse the steps above	
Note 1	Once you have reconnected power cords, and engaged the circuit breakers, etc., it is a good idea to start by booting up vattdata. Let it do its thing for 5-10 mins, then look at its terminal. It should have a menu of a dozen options to choose from (it also appears during shutdown).	
Note 2	😊 The GPS unit can take up to 10 minutes to startup fully (two blue lights: Ready and Power). 😊 Turn it on as immediately after having plugged in the raceway cables and closed all circuit breakers.	
Note 3	Do not attempt to boot any of the other servers until vattdata is running (wait time ~10 mins)	
Note 4	Boot VATTtel (follow these instructions: (Re)Booting VATTtel) only when vattdata is running. VATTtel uses its ancient network card to ftp a *.cmd file from vattdata, and it does not respond well to time pressure.	
Note 5	Coming out of lightning shutdown the guide box is likely to run into communication problems. The remedy is to run the INDImon script (its launcher on VATTcontrol's desktop is labeled Restart indidriver), selecting option (3) Filter/Guidebox driver.	

From:
<https://lavinia.as.arizona.edu/~tscopewiki/> - **MOON**

Permanent link:
https://lavinia.as.arizona.edu/~tscopewiki/doku.php?id=vatt:vatt_lightning_shutdown_checklist&rev=1625703385

Last update: **2021/07/07 17:16**

